Configuring IP Multicasting and Multimedia Services

BayRS Version 13.00
Site Manager Software Version 7.00

BCC Version 4.05

Part No. 303527-A Rev. 00
October 1998

Bay Networks *Where Information Flows.*™

4401 Great America Parkway
Santa Clara, CA 95054

8 Federal Street
Billerica, MA 01821

Copyright © 1998 Bay Networks, Inc.

All rights reserved. Printed in the USA. October 1998.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Bay Networks, Inc.

The software described in this document is furnished under a license agreement and may only be used in accordance with the terms of that license. A summary of the Software License is included in this document.

Trademarks

ACE, AFN, AN, BCN, BLN, BN, BNX, CN, FRE, LN, Optivity, PPX, Quick2Config, and Bay Networks are registered trademarks and Advanced Remote Node, ANH, ARN, ASN, BayRS, BaySecure, BayStack, BayStream, BCC, BCNX, BLNX, EZ Install, EZ Internetwork, EZ LAN, FN, IP AutoLearn, PathMan, RouterMan, SN, SPEX, Switch Node, System 5000, and the Bay Networks logo are trademarks of Bay Networks, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

Restricted Rights Legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

Statement of Conditions

In the interest of improving internal design, operational function, and/or reliability, Bay Networks, Inc. reserves the right to make changes to the products described in this document without notice.

Bay Networks, Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product may be Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

Bay Networks, Inc. Software License Agreement

NOTICE: Please carefully read this license agreement before copying or using the accompanying software or installing the hardware unit with pre-enabled software (each of which is referred to as "Software" in this Agreement). BY COPYING OR USING THE SOFTWARE, YOU ACCEPT ALL OF THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. THE TERMS EXPRESSED IN THIS AGREEMENT ARE THE ONLY TERMS UNDER WHICH BAY NETWORKS WILL PERMIT YOU TO USE THE SOFTWARE. If you do not accept these terms and conditions, return the product, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

1. License Grant. Bay Networks, Inc. ("Bay Networks") grants the end user of the Software ("Licensee") a personal, nonexclusive, nontransferable license: a) to use the Software either on a single computer or, if applicable, on a single authorized device identified by host ID, for which it was originally acquired; b) to copy the Software solely for backup purposes in support of authorized use of the Software; and c) to use and copy the associated user manual solely in support of authorized use of the Software by Licensee. This license applies to the Software only and does not extend to Bay Networks Agent software or other Bay Networks software products. Bay Networks Agent software or other Bay Networks software products are licensed for use under the terms of the applicable Bay Networks, Inc. Software License Agreement that accompanies such software and upon payment by the end user of the applicable license fees for such software.

2. Restrictions on use; reservation of rights. The Software and user manuals are protected under copyright laws. Bay Networks and/or its licensors retain all title and ownership in both the Software and user manuals, including any revisions made by Bay Networks or its licensors. The copyright notice must be reproduced and included with any copy of any portion of the Software or user manuals. Licensee may not modify, translate, decompile, disassemble, use for any competitive analysis, reverse engineer, distribute, or create derivative works from the Software or user manuals or any copy, in whole or in part. Except as expressly provided in this Agreement, Licensee may not copy or transfer the Software or user manuals, in whole or in part. The Software and user manuals embody Bay Networks' and its licensors' confidential and proprietary intellectual property. Licensee shall not sublicense, assign, or otherwise disclose to any third party the Software, or any information about the operation, design, performance, or implementation of the Software and user manuals that is confidential to Bay Networks and its licensors; however, Licensee may grant permission to its consultants, subcontractors, and agents to use the Software at Licensee's facility, provided they have agreed to use the Software only in accordance with the terms of this license.

3. Limited warranty. Bay Networks warrants each item of Software, as delivered by Bay Networks and properly installed and operated on Bay Networks hardware or other equipment it is originally licensed for, to function substantially as described in its accompanying user manual during its warranty period, which begins on the date Software is first shipped to Licensee. If any item of Software fails to so function during its warranty period, as the sole remedy Bay Networks will at its discretion provide a suitable fix, patch, or workaround for the problem that may be included in a future Software release. Bay Networks further warrants to Licensee that the media on which the Software is provided will be free from defects in materials and workmanship under normal use for a period of 90 days from the date Software is first shipped to Licensee. Bay Networks will replace defective media at no charge if it is returned to Bay Networks during the warranty period along with proof of the date of shipment. This warranty does not apply if the media has been damaged as a result of accident, misuse, or abuse. The Licensee assumes all responsibility for selection of the Software to achieve Licensee's intended results and for the installation, use, and results obtained from the Software. Bay Networks does not warrant a) that the functions contained in the software will meet the Licensee's requirements, b) that the Software will operate in the hardware or software combinations that the Licensee may select, c) that the operation of the Software will be uninterrupted or error free, or d) that all defects in the operation of the Software will be corrected. Bay Networks is not obligated to remedy any Software defect that cannot be reproduced with the latest Software release. These warranties do not apply to the Software if it has been (i) altered, except by Bay Networks or in accordance with its instructions; (ii) used in conjunction with another vendor's product, resulting in the defect; or (iii) damaged by improper environment, abuse, misuse, accident, or negligence. THE FOREGOING WARRANTIES AND LIMITATIONS ARE EXCLUSIVE REMEDIES AND ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Licensee is responsible for the security of

its own data and information and for maintaining adequate procedures apart from the Software to reconstruct lost or altered files, data, or programs.

4. Limitation of liability. IN NO EVENT WILL BAY NETWORKS OR ITS LICENSORS BE LIABLE FOR ANY COST OF SUBSTITUTE PROCUREMENT; SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES; OR ANY DAMAGES RESULTING FROM INACCURATE OR LOST DATA OR LOSS OF USE OR PROFITS ARISING OUT OF OR IN CONNECTION WITH THE PERFORMANCE OF THE SOFTWARE, EVEN IF BAY NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL THE LIABILITY OF BAY NETWORKS RELATING TO THE SOFTWARE OR THIS AGREEMENT EXCEED THE PRICE PAID TO BAY NETWORKS FOR THE SOFTWARE LICENSE.

5. Government Licensees. This provision applies to all Software and documentation acquired directly or indirectly by or on behalf of the United States Government. The Software and documentation are commercial products, licensed on the open market at market prices, and were developed entirely at private expense and without the use of any U.S. Government funds. The license to the U.S. Government is granted only with restricted rights, and use, duplication, or disclosure by the U.S. Government is subject to the restrictions set forth in subparagraph (c)(1) of the Commercial Computer Software—Restricted Rights clause of FAR 52.227-19 and the limitations set out in this license for civilian agencies, and subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause of DFARS 252.227-7013, for agencies of the Department of Defense or their successors, whichever is applicable.

6. Use of Software in the European Community. This provision applies to all Software acquired for use within the European Community. If Licensee uses the Software within a country in the European Community, the Software Directive enacted by the Council of European Communities Directive dated 14 May, 1991, will apply to the examination of the Software to facilitate interoperability. Licensee agrees to notify Bay Networks of any such intended examination of the Software and may procure support and assistance from Bay Networks.

7. Term and termination. This license is effective until terminated; however, all of the restrictions with respect to Bay Networks' copyright in the Software and user manuals will cease being effective at the date of expiration of the Bay Networks copyright; those restrictions relating to use and disclosure of Bay Networks' confidential information shall continue in effect. Licensee may terminate this license at any time. The license will automatically terminate if Licensee fails to comply with any of the terms and conditions of the license. Upon termination for any reason, Licensee will immediately destroy or return to Bay Networks the Software, user manuals, and all copies. Bay Networks is not liable to Licensee for damages in any form solely by reason of the termination of this license.

8. Export and Re-export. Licensee agrees not to export, directly or indirectly, the Software or related technical data or information without first obtaining any required export licenses or other governmental approvals. Without limiting the foregoing, Licensee, on behalf of itself and its subsidiaries and affiliates, agrees that it will not, without first obtaining all export licenses and approvals required by the U.S. Government: (i) export, re-export, transfer, or divert any such Software or technical data, or any direct product thereof, to any country to which such exports or re-exports are restricted or embargoed under United States export control laws and regulations, or to any national or resident of such restricted or embargoed countries; or (ii) provide the Software or related technical data or information to any military end user or for any military end use, including the design, development, or production of any chemical, nuclear, or biological weapons.

9. General. If any provision of this Agreement is held to be invalid or unenforceable by a court of competent jurisdiction, the remainder of the provisions of this Agreement shall remain in full force and effect. This Agreement will be governed by the laws of the state of California.

Should you have any questions concerning this Agreement, contact Bay Networks, Inc., 4401 Great America Parkway, P.O. Box 58185, Santa Clara, California 95054-8185.

LICENSEE ACKNOWLEDGES THAT LICENSEE HAS READ THIS AGREEMENT, UNDERSTANDS IT, AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. LICENSEE FURTHER AGREES THAT THIS AGREEMENT IS THE ENTIRE AND EXCLUSIVE AGREEMENT BETWEEN BAY NETWORKS AND LICENSEE, WHICH SUPERSEDES ALL PRIOR ORAL AND WRITTEN AGREEMENTS AND COMMUNICATIONS BETWEEN THE PARTIES PERTAINING TO THE SUBJECT MATTER OF THIS AGREEMENT. NO DIFFERENT OR ADDITIONAL TERMS WILL BE ENFORCEABLE AGAINST BAY NETWORKS UNLESS BAY NETWORKS GIVES ITS EXPRESS WRITTEN CONSENT, INCLUDING AN EXPRESS WAIVER OF THE TERMS OF THIS AGREEMENT.

Contents

Preface

Before You Begin xv
Text Conventions xvi
Acronyms xvii
Bay Networks Technical Publications xix
How to Get Help xix

Chapter 1
Multicasting and Multimedia Overview

Multicast Host Groups 1-2
Multicast Addresses 1-3
Internet Group Management Protocol 1-3
Distance Vector Multicast Routing Protocol 1-3
Multicast Extensions to OSPF 1-4
Quality of Service Extensions to OSPF 1-4
Resource Reservation Protocol 1-4
Bay Networks Resource Manager 1-4
IGMP Relay 1-5
Multicast Table Manager 1-5

Chapter 2
Starting Multicasting and Multimedia Services

Starting IGMP 2-2
Starting DVMRP 2-3
Starting MOSPF 2-4
Starting RSVP 2-5

Chapter 3
Configuring and Customizing IGMP

IGMP Concepts and Terminology 3-2
IGMP Queries 3-2
IGMP Host Reports 3-3
Host Leave Messages 3-3
Customizing Global IGMP 3-4
Enabling and Disabling IGMP 3-5
Estimating the Number of Groups 3-6
Specifying a Version Threshold Time 3-8
Configuring Logging 3-9
Enabling Join Acknowledgments 3-10
Specifying a Forwarding Cache Limit 3-11
Accepting a Nonlocal Report 3-12
Customizing IGMP on an Interface 3-13
Enabling and Disabling IGMP on an Interface 3-14
Specifying a Query Rate 3-15
Specifying a Membership Timeout Interval 3-17
Specifying a Designated Router Timeout Interval 3-18
Specifying a Maximum Host Response Time 3-19
Specifying the Lifetime of a Cache Entry for Mtrace 3-20
Configuring a Static Host Entry 3-21
Configuring an IGMP Boundary Group 3-22
Configuring IGMP Policies 3-23

Chapter 4
Customizing DVMRP

DVMRP Concepts and Terminology 4-2
Neighbor Connections 4-2
Source Route Advertisements 4-4
How DVMRP Chooses a Route 4-5
Routing Table 4-6
Shortest-Path Trees 4-7
Customizing DVMRP Globally 4-8
Disabling and Reenabling DVMRP 4-9
Setting the Update Interval 4-10

Configuring Tree Pruning 4-11
Configuring DVMRP Timers 4-12
Setting the Route Expiration Timer 4-12
Setting the Garbage Timer 4-13
Setting the Neighbor Report Timer 4-14
Setting the Leaf Timer 4-15
Specifying a Probe Interval 4-16
Specifying a Route Switch Interval 4-17
Estimating the Number of Routes 4-18
Logging Debugging Messages 4-19
Specifying the Maximum Number of Routes 4-20
Enabling and Disabling Routing Policies 4-21
Customizing DVMRP on a Circuit 4-22
Disabling and Reenabling DVMRP on a Circuit 4-22
Disabling Multicast Support on a Unicast Tunnel 4-23
Calculating a Route Metric and Comparing Route Costs 4-24
Specifying a Threshold 4-25
Configuring a Forwarding Table 4-27
Disabling Advertisement of Local Networks 4-29
Advertising a Default Route 4-30
Listening for a Default Route 4-31
Accepting a Report from a Nonstandard DVMRP Neighbor 4-32
Configuring a Tunnel 4-33
Supplying Addresses for the Tunnel 4-34
Disabling and Reenabling the Tunnel 4-35
Choosing the Encapsulation Mode 4-36
Specifying the Cost 4-37
Specifying a TTL 4-38
Configuring a Forwarding Table for the Tunnel 4-39
Advertising a Default Route 4-41
Listening for a Default Route 4-42
Specifying an Encapsulation Mode for Control Messages 4-43
Accepting a Report from a Nonstandard DVMRP Neighbor 4-44
Configuring DVMRP Announce Policies 4-45

Chapter 5
Customizing OSPF Multicast Extensions

MOSPF Overview 5-2
Configuring MOSPF Globally 5-4
Enabling Deterministic Multicasting 5-6
Specifying a Forwarding Timeout Value 5-7
Specifying a Maximum Number of Queued Packets 5-8
Enabling Dynamic TTL 5-9
Configuring Multicast Forwarding on an OSPF Interface 5-10
Configuring Multicast-Capable External Routes 5-11
Configuring MOSPF Announce Policies 5-12

Chapter 6
Configuring QOSPF

Enabling the Deterministic Holddown Feature 6-3
Enabling Route Pinning 6-4
Enabling the Opaque Capability 6-5
Enabling the Opaque Capability on an Interface 6-6

Chapter 7
Configuring RSVP

How RSVP Works 7-2
Configuring RSVP Globally 7-4
Disabling and Reenabling RSVP 7-4
Choosing a Slot 7-5
Configuring RSVP Message Logging 7-6
Configuring RSVP on an Interface 7-7
Disabling and Reenabling RSVP on an Interface 7-7
Setting the RSVP Default Refresh Timer 7-8
Setting the RSVP Default Lifetime Multiplier 7-9
Setting the RSVP Refresh Blockade Multiplier 7-10
Setting the TTL Override 7-11
Setting the Route Delay Value 7-12
Enabling and Disabling UDP Encapsulation 7-13

Chapter 8
Reserving Line Resources

About Line Resource Reservation 8-2
Resource Manager 8-2
Supported Media 8-3
How the Resource Manager Works with RSVP 8-3
Setting the Estimated Bandwidth 8-4
Setting the Reservable Bandwidth 8-5
Specifying the Traffic Queuing Algorithm 8-6
Specifying the LRM Policing Algorithm 8-7
Setting the Bandwidth Interval 8-8
Setting the Inflate Reservations Percentage 8-9
Specifying the Unreserved Policing Algorithm 8-10
Specifying the Unreserved Queue Length 8-11
Specifying the Multiline Select Algorithm 8-12
Setting the Multiline Threshold Bandwidth 8-13
Setting the Reservation Latency 8-14
Setting the Maximum Reservable Bandwidth for a Dataflow 8-15
Setting the Maximum Buffer Space for a Dataflow 8-16

Chapter 9
Configuring IGMP Relay

Concepts and Terminology 9-2
Enabling and Disabling IGMP Relay Globally 9-7
Specifying a Timeout Value for Multicast Table Entries 9-9
Configuring Upstream Data Forwarding 9-10
Specifying the Relay Interface Type 9-11
Configuring Unsolicited Reports on an Upstream Interface 9-13
Configuring an AS Boundary Router for Use with IGMP Relay 9-16
Configuring a Backup MOSPF Boundary Router 9-18
Configuring IGMP Relay with Router Redundancy 9-19

Appendix A
Site Manager Parameters

DVMRP Parameters A-2
DVMRP Global Parameters A-2
DVMRP Circuit Parameters A-7
DVMRP Tunnel Parameters A-11
IGMP Parameters A-15
IGMP Global Configuration Parameters A-15
IGMP Static Host Parameters A-19
IGMP Entry Interface Parameters A-20
IP Configuration Parameters A-23
Resource Manager Parameters A-25
OSPF Parameters for Multicast and QoS Extensions A-31
OSPF Global Parameters A-31
OSPF Interface Parameters A-34
RSVP Parameters A-35
RSVP Global Parameters A-35
RSVP Interface Parameters A-37
Announce Policy Parameters for Both DVMRP and MOSPF A-39
DVMRP-Specific Announce Policy Parameters A-43
IGMP Group Policy Parameters A-44
MTM Static Forwarding Policy Parameters A-48
IGMP Boundary Group Parameters A-51

Appendix B
Multicasting Tools

mtrace B-2
mrinfo B-4
rsvp B-5

Index

Figures

Figure 4-1. Multicast Routers 4-3
Figure 5-1. OSPF Autonomous Systems 5-3
Figure 6-1. QOSPF Topology 6-2
Figure 7-1. RSVP Path Message 7-2
Figure 7-2. RSVP Reserve Message 7-3
Figure 9-1. Multicast Network Topology with an IGMP Relay Device 9-3
Figure 9-2. IGMP-R Host Queries and Responses 9-4
Figure 9-3. IGMP-R and Upstream Multicast Data 9-5
Figure 9-4. IGMP-R and Downstream Multicast Data 9-6
Figure 9-5. IGMP-R Routing Protocols 9-17
Figure 9-6. IGMP Relay with Primary and Backup Boundary Routers 9-18
Figure 9-7. IGMP Relay with Router Redundancy 9-19

Tables

Table 4-1. Parts of a Routing Table Entry 4-6
Table 4-2. Recommended TTL and Threshold Values 4-25
Table 9-1. IGMP Relay Forwarding Options 9-10
Table 9-2. IGMP Relay Interface Types 9-12
Table 9-3. Unsolicited IGMP Report Interval 9-14
Table B-1. Mtrace Options B-2
Table B-2. Mrinfo Options B-4
Table B-3. IP Subcommands B-5
Table B-4. Options for rsvp Subcommands B-6

Preface

This guide describes configuring IGMP, DVMRP, MOSPF, QOSPF, RSVP, and line services on a Bay Networks® router.

You can use the Bay Command Console (BCC™) or Site Manager to configure IGMP on a router. In this guide, you will find instructions for using both the BCC and Site Manager.

Before You Begin

Before using this guide, you must complete the following procedures. For a new router:

- Install the router (see the installation manual that came with your router).
- Connect the router to the network and create a pilot configuration file (see *Quick-Starting Routers*, *Configuring BayStack Remote Access*, or *Connecting ASN Routers to a Network)*.

Make sure that you are running the latest version of Bay Networks BayRS™ and Site Manager software. For information about upgrading BayRS and Site Manager, see the upgrading guide for your version of BayRS.

Text Conventions

This guide uses the following text conventions:

angle brackets (< >)	Indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when entering the command. Example: If the command syntax is: **ping** *<ip_address>*, you enter: **ping 192.32.10.12**
bold text	Indicates text that you need to enter and command names and options. Example: Enter **show ip** {**alerts** | **routes**} Example: Use the **dinfo** command.
braces ({})	Indicate required elements in syntax descriptions where there is more than one option. You must choose only one of the options. Do not type the braces when entering the command. Example: If the command syntax is: **show ip** {**alerts** | **routes**}, you must enter either: **show ip alerts** or **show ip routes**.
brackets ([ ])	Indicate optional elements in syntax descriptions. Do not type the brackets when entering the command. Example: If the command syntax is: **show ip interfaces** [**-alerts**], you can enter either: **show ip interfaces** or **show ip interfaces -alerts**.
ellipsis points (. . .)	Indicate that you repeat the last element of the command as needed. Example: If the command syntax is: **ethernet/2/1** [<*parameter*> <*value*>] . . ., you enter **ethernet/2/1** and as many parameter-value pairs as needed.

italic text	Indicates file and directory names, new terms, book titles, and variables in command syntax descriptions. Where a variable is two or more words, the words are connected by an underscore. Example: If the command syntax is: **show at** <*valid_route*> *valid_route* is one variable and you substitute one value for it.
`screen text`	Indicates system output, for example, prompts and system messages. Example: `Set Bay Networks Trap Monitor Filters`
separator (>)	Shows menu paths. Example: Protocols > IP identifies the IP option on the Protocols menu.
vertical line (|)	Separates choices for command keywords and arguments. Enter only one of the choices. Do not type the vertical line when entering the command. Example: If the command syntax is: **show ip** {**alerts** | **routes**}, you enter either: **show ip alerts** or **show ip routes**, but not both.

Acronyms

AUI	Attachment Unit Interface
BootP	Bootstrap Protocol
BRI	Basic Rate Interface
CCITT	International Telegraph and Telephone Consultative Committee (now ITU-T)
CSMA/CD	carrier sense multiple access with collision detection
DLCMI	Data Link Control Management Interface
GUI	graphical user interface
HDLC	high-level data link control

IP	Internet Protocol
ISDN	Integrated Services Digital Network
ISO	International Organization for Standardization
ITU-T	International Telecommunications Union-Telecommunications (formerly CCITT)
LAN	local area network
MAC	media access control
MAU	media access unit
MDI-X	media-dependent interface with crossover
NBMA	nonbroadcast multi-access
OSI	Open Systems Interconnection
OSPF	Open Shortest Path First (Protocol)
PPP	Point-to-Point Protocol
SMDS	switched multimegabit data service
SNMP	Simple Network Management Protocol
STP	shielded twisted-pair
TCP/IP	Transmission Control Protocol/Internet Protocol
Telnet	Telecommunication Network
TFTP	Trivial File Transfer Protocol
TPE	twisted-pair Ethernet
UTP	unshielded twisted-pair
WAN	wide area network

Bay Networks Technical Publications

You can now print Bay Networks technical manuals and release notes free, directly from the Internet. Go to *support.baynetworks.com/library/tpubs/*. Find the Bay Networks product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Using Adobe Acrobat Reader, you can open the manuals and release notes, search for the sections you need, and print them on most standard printers. You can download Acrobat Reader free from the Adobe Systems Web site, *www.adobe.com*.

You can purchase Bay Networks documentation sets, CDs, and selected technical publications through the Bay Networks Collateral Catalog. The catalog is located on the World Wide Web at *support.baynetworks.com/catalog.html* and is divided into sections arranged alphabetically:

- The “CD ROMs” section lists available CDs.
- The “Guides/Books” section lists books on technical topics.
- The “Technical Manuals” section lists available printed documentation sets.

Make a note of the part numbers and prices of the items that you want to order. Use the “Marketing Collateral Catalog description” link to place an order and to print the order form.

How to Get Help

For product assistance, support contracts, or information about educational services, go to the following URL:

http://www.baynetworks.com/corporate/contacts/

Or telephone the Bay Networks Technical Solutions Center at:

800-2LANWAN

Chapter 1
Multicasting and Multimedia Overview

This overview covers the following topics:

Topic	Page
Multicast Host Groups	1-2
Multicast Addresses	1-3
Internet Group Management Protocol	1-3
Distance Vector Multicast Routing Protocol	1-3
Multicast Extensions to OSPF	1-4
Quality of Service Extensions to OSPF	1-4
Resource Reservation Protocol	1-4
Bay Networks Resource Manager	1-4
IGMP Relay	1-5
Multicast Table Manager	1-5

Multicast Host Groups

IP multicasting is a method for addressing, routing, and delivering a datagram to a collection of receivers -- called a *host group.*

Host groups can be permanent or transient:

- A *permanent host group* has a well-known, administratively assigned IP multicast group address. The address, not the membership, is permanent and defines the group. A permanent host group can consist of zero or more members.
- A *transient host group* exists only as long as it has members that need its services. IP addresses in the multicast range that are not reserved for permanent groups are available for dynamic assignment to transient host groups.

Any host system on any IP network can send a message to a multicast group using the group's IP multicast address. To receive a message addressed to a multicast group, however, the host must be a member of the group and must reside on a network where that group is registered with a local multicast router.

An IP multicasting host group can consist of zero or more members and places no restrictions on its membership. Host members can reside anywhere; they can join and leave the group at any time; and they can be members of more than one group at the same time. In order to receive a multicast message from a host group, a host must be a member of the group. However, anyone can send a multicast datagram: a host does not need to be a member of a group to send a multicast message to its members.

In general, hosts that are members of the same group reside on different networks. However, a range of multicast addresses (224.0.0.*x*) is reserved for groups that are locally scoped. All message traffic for these hosts remains on the local network. Hosts that belong to a group in this address range and that reside in different networks will not receive each other's message traffic.

Note: Multicast data packets are affected by traffic filters. Therefore, you must ensure that traffic filters configured on a multicast router do not prevent a host that is a member of a group from receiving packets intended for that group.

Multicast Addresses

Each host group is assigned a unique multicast address. To reach all members of the group, a sender uses the multicast address as the destination address of the datagram.

An IP Version 4 multicast address is a Class D address (the high-order bits are set to 1110) from 224.0.0.0 to 239.255.255.255.

The block of addresses from 224.0.0.1 to 224.0.0.255 is reserved for routing protocols and other low-level protocols. Multicast routers will not forward datagrams with addresses in this range.

Internet Group Management Protocol

The Internet Group Management Protocol (IGMP) has the following characteristics:

- Allows a host to register group memberships with the local queries router to receive any datagrams sent to this router and targeted to a group with a specific IP multicast address.
- Allows a router to learn the existence of group members on its directly attached networks. The router periodically sends a general group query message to each of its local networks. Any host that is a member of a multicasting group identifies itself by sending a response.

IGMP is described in Chapter 3.

Distance Vector Multicast Routing Protocol

DVMRP is a distance vector type of multicast routing protocol. It advertises shortest-path routes to multicasting *source networks* -- that is, any network containing hosts that have the capability to issue multicast datagrams. (In this respect, DVMRP is the opposite of RIP, which advertises routes to destination networks.)

DVMRP is described in Chapter 4.

Multicast Extensions to OSPF

Multicasting Extensions to OSPF (MOSPF) enhances the OSPF protocol by providing capabilities that allow a router to forward multicast IP traffic within an OSPF Version 2 autonomous system.

For instructions on configuring MOSPF, see Chapter 5.

Quality of Service Extensions to OSPF

QOSPF is an extension of OSPF and MOSPF that works in conjunction with the Resource Reservation Protocol to provide quality of service (QoS) for multicast data flows.

QOSPF is described in Chapter 6.

Resource Reservation Protocol

The Resource Reservation Protocol (RSVP) allows host systems in an IP network to reserve resources on RSVP-capable routers for unicast or multicast dataflows. (A dataflow is a transmission of packets from a source to one or more destinations requiring a certain QoS.)

RSVP is described in Chapter 7.

Bay Networks Resource Manager

The Bay Networks Resource Manager lets you define a certain percentage of a line's bandwidth as *reservable*. Applications that require a guaranteed quality of service can negotiate for the reservable bandwidth. When the router honors a reservation request, the Resource Manager allocates bandwidth from the reservable bandwidth, reducing the bandwidth available for other requests.

For information about the Bay Networks Resource Manager, see Chapter 8.

IGMP Relay

A router configured as an IGMP Relay (IGMP-R) device provides the following services for an MOSPF AS boundary router:

- Solicits multicast group membership information by sending IGMP host membership queries to hosts on its attached local networks
- Receives host membership reports and unsolicited join messages from hosts on attached networks and forwards them to the MOSPF boundary router
- Forwards multicast data to group members on locally attached networks

For information about IGMP Relay, see Chapter 9.

Multicast Table Manager

The Multicast Table Manager (MTM) makes it possible for different multicast protocols to work together on the same router. MTM does the following:

- Manages DVMRP and MOSPF
- Provides multicast routing support for RSVP
- Supports MOSPF special features
- Supports multicast tools for tracing routes
- Maintains a multicast forwarding cache
- Forwards multicast traffic

Chapter 2
Starting Multicasting and Multimedia Services

This chapter explains how to perform a basic configuration -- that is, a configuration using all available defaults -- for the IP multicast services described in this manual.

Topic	Page
Starting IGMP	2-2
Starting DVMRP	2-3
Starting MOSPF	2-4
Starting RSVP	2-5

Starting IGMP

When you configure any multicasting protocol described in this manual, Site Manager automatically configures IGMP on the slot and circuit.

IGMP is required for all types of multicasting. If you want the router to receive and forward multicast packets (that is, packets with destination addresses from 224.0.0.255 to 239.255.255.255), IGMP must be running on the slot and circuit -- even if the circuit is a point-to-point circuit that will not be involved in IGMP group queries and join messages.

Starting DVMRP

To start DVMRP on the router:

1. **Configure a circuit on a slot and connector.**
2. **Configure an IP interface on the circuit.**
3. **Add DVMRP to the IP interface.**

For information and instructions on using Site Manager to configure a circuit on a slot and connector, see *Configuring WAN Line Services* or *Configuring Ethernet, FDDI, and Token Ring Services*. When you have successfully configured the circuit, the Select Protocols window opens. Proceed as follows:

Site Manager Procedure	
You do this	**System responds**
1. In the Select Protocols window, choose the following protocols: • **IP** • **DVMRP** Then click on **OK**.	The IP Configuration window opens.
2. Set the following parameters: • **IP Address** • **Subnet Mask** • **Transmit Bcast Addr** • **UnNumbered Assoc Address** Click on **Help** or see the parameter descriptions beginning on page A-23.	
3. Click on **OK**.	Site Manager returns you to the Configuration Manager window.

When you configure DVMRP on an IP interface, DVMRP is also configured globally on the router.

DVMRP is now running on the router with default values for all global and interface parameters. You customize DVMRP by modifying DVMRP parameters. For information and instructions, see Chapter 4.

Starting MOSPF

MOSPF is a multicasting extension of OSPF. To enable MOSPF, you must add OSPF to an IP interface and enable MOSPF multicast extensions to support one of the following types of multicasting:

- Intra-area multicasting
- Intra-area and inter-area multicasting
- Intra-area and inter-AS multicasting
- All multicasting

For information about MOSPF multicasting types, see Chapter 5.

Site Manager Procedure	
You do this	**System responds**
1. Configure OSPF on the router as described in *Configuring IP Services*.	
2. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
3. Choose **IP**.	The IP menu opens.
4. Choose **OSPF**.	The OSPF menu opens.
5. Choose **Global**.	The Edit OSPF Global Parameters window opens.
6. Click on the **Multicast Extensions** parameter. Site Manager: Multicast Extensions parameter: page A-31	
7. Choose the type of MOSPF you want to configure, and then click on **OK**.	

Starting RSVP

To start RSVP on the router:

1. **Configure a circuit on a slot and connector.**
2. **Configure an IP interface on the circuit.**
3. **Add RSVP to the IP interface.**

For information and instructions on using Site Manager to configure a circuit on a slot and connector, see see *Configuring WAN Line Services* or *Configuring Ethernet, FDDI, and Token Ring Services*. When you have successfully configured the circuit, the Select Protocols window opens. Proceed as follows:

Site Manager Procedure	
You do this	**System responds**
1. In the Select Protocols window, choose the following protocols: • **IP** • **RSVP** Then click on **OK**.	The IP Configuration window opens.
2. Set the following parameters: • **IP Address** • **Subnet Mask** • **Transmit Bcast Addr** • **UnNumbered Assoc Address** Click on **Help** or see the parameter descriptions beginning on page A-23.	
3. Click on **OK**.	The Initial RSVP Global Parameters widow appears.
4. Click on **Save**.	Site Manager queries you to create line resources.
5. Click on **OK**.	The Edit Line Resources window opens.
6. Edit the following parameters: • **Estimated Bandwidth** • **Reservable Bandwidth** Click on **Help** or see the parameter descriptions beginning on page A-25.	Site Manager returns you to the Configuration Manager window.
7. Click on **OK**.	Site Manager returns you to the Configuration Manager window.

RSVP is now running on the router with default values for all parameters. You customize RSVP by modifying RSVP parameters. For information and instructions, see Chapter 7.

Chapter 3
Configuring and Customizing IGMP

This chapter covers the following topics describing the Internet Group Management Protocol (IGMP):

Topic	Page
IGMP Concepts and Terminology	3-2
Customizing Global IGMP	3-4
Customizing IGMP on an Interface	3-13
Configuring a Static Host Entry	3-21
Configuring an IGMP Boundary Group	3-22
Configuring IGMP Policies	3-23

IGMP Concepts and Terminology

The Internet Group Management Protocol (IGMP) allows hosts to communicate their desired group memberships to their local queries router to receive any datagrams sent to this router and targeted to a group with a specific IP multicast address. Bay Networks routers support IGMP Version 2.

A router communicates with the hosts on a local network by sending IGMP queries. Hosts respond by issuing IGMP reports.

This section covers the following topics:

Topic	Page
IGMP Queries	3-2
IGMP Host Reports	3-3
Host Leave Messages	3-3

IGMP Queries

A router running IGMP periodically sends host membership queries to its attached local networks. Routers that conform to RFC 1112 generate Version 1 queries. Bay Networks routers configured with IGMP generate Version 2 queries.

If multiple IGMP routers exist on the network, Bay Networks routers designate one router to send host member questions, using the following rules:

- Choose a router that generates Version 1 queries over a router that generates Version 2 queries.
- Choose the router with the lowest IP address.

IGMP Host Reports

A host that receives a membership query from a local router can respond with a *host membership report*, one report for each joined multicast group. A host that receives a query delays its reply by a random interval and listens for a reply from any other host in the same host group. Consider a network that includes two host members -- Host A and Host B -- of the same multicast group. The router sends out a host membership query on the local network. Host A and Host B both receive the query and listen on the network for a host membership report. Host B's delay time expires first, so it responds to the query with a membership report. Hearing the response, Host A does not send a report of its own for the same group.

Each query from a router to a host includes a code field. IGMP inserts a value -- *n* -- into this field specifying the maximum time in tenths of a second within which the host must issue a reply. The host uses this value to calculate a random value between 0 and *n* tenths of a second for the period that it waits before sending a response.

If at least one host on the local network specifies that it is a member of a given group, the router will forward to that network all datagrams bearing the group's multicast address.

Upon initialization, the host may immediately issue a report for each of its supported multicast groups. The router accepts and processes these asynchronous reports the same way it accepts requested reports.

Once in a steady state, hosts and routers communicate in a way that minimizes the exchange of queries and reports.

Host Leave Messages

When a Version 2 host leaves a group, it issues a *host leave message*. The multicast router on the network issues a group-specific query to determine whether there are other group members on the network. If no host responds to the query, the router assumes that no members belonging to that group exist on that interface.

Customizing Global IGMP

When you configure a multicasting protocol on the router, IGMP is automatically enabled with default values for all global parameters. You customize global IGMP by modifying these parameters as described under the following topics:

Topic	Page
Enabling and Disabling IGMP	3-5
Estimating the Number of Groups	3-6
Specifying a Version Threshold Time	3-8
Configuring Logging	3-9
Enabling Join Acknowledgments	3-10
Specifying a Forwarding Cache Limit	3-11
Accepting a Nonlocal Report	3-12

Enabling and Disabling IGMP

When you configure IGMP on the router, IGMP is automatically enabled.

You can use the BCC or Site Manager to disable and reenable IGMP on the router.

Using the BCC

Navigate to the global IGMP prompt and enter:

state *state*

state is one of the following:

enabled
disabled

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **Enable** parameter. Site Manager: Enable parameter: page A-15	
6. Click on **Save**.	You return to the Configuration Manager window.

Estimating the Number of Groups

By default, IGMP estimates that 20 groups will be simultaneously active on this router.

This estimate allows the router to utilize memory efficiently; exceeding this size during router operation will not cause an error but may cause the router to consume more memory than required.

Note: You do not need to include in the count any group from 224.0.0.0 to 224.0.0.255.

You can use the BCC or Site Manager to supply an estimate from 5 to 65,535 groups.

Using the BCC

Navigate to the global IGMP prompt and enter:

estimated-groups *groups*

groups is an integer from 5 to 65,535.

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **Estimated Groups** parameter. Site Manager: Estimated Groups parameter: page A-16	
6. Click on **Save**.	You return to the Configuration Manager window.

Specifying a Version Threshold Time

By default, 540 seconds can elapse after IGMP detects a Version 1 query before IGMP tries to become the designated querier.

The value you specify should be greater than the Version 1 query rate of all IGMP speakers on all networks directly connected to the router.

You can use the BCC or Site Manager to specify a version threshold time from 1 second to 65,535 seconds.

Using the BCC

Navigate to the global IGMP prompt and enter:

version-threshold *threshold*

threshold is the number of seconds from 1 to 65,535.

For example, the following command sets the version threshold time to 500 seconds:

```
igmp# version-threshold 500
igmp#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **Version Threshold Time** parameter. Site Manager: Version Threshold Time parameter: page A-16	
6. Click on **Save**.	You return to the Configuration Manager window.

Configuring Logging

You can use the BCC or Site Manager to specify the messages you want IGMP to log.

Using the BCC

Navigate to the global IGMP prompt and enter:

debug-log-flag *flag*

flag is an integer indicating the messages you want to log.

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **Debug** parameter. Site Manager: Debug parameter: page A-17	
6. Click on **Save**.	You return to the Configuration Manager window.

Enabling Join Acknowledgments

By default, IGMP does not respond with an acknowledgment to join requests from host groups.

Using the following Site Manager procedure, you can configure IGMP globally to respond to a join request by sending an IGMP query to the group.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **Join Ack Enable** parameter. Site Manager: Join Ack Enable parameter: page A-16	
6. Click on **Save**.	You return to the Configuration Manager window.

Note: This is a proprietary Bay Networks function. It is not part of the standard IGMP protocol.

Specifying a Forwarding Cache Limit

By default, IGMP allows a maximum of 512 entries in the MTM forwarding cache. This affects all multicasting protocols.

The MTM cache must be at least as large as individual routing protocol caches (for example, the DVMRP cache).

You can use the following Site Manager procedure to set the forwarding cache to a different value.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **Forward Cache Limit** parameter. Site Manager: Forward Cache Limit parameter: page A-17	
6. Click on **Save**.	You return to the Configuration Manager window.

Accepting a Nonlocal Report

By default, IGMP rejects join and leave messages from nonlocal networks.

You can use the BCC or Site Manager to control the way IGMP handles nonlocal reports.

Using the BCC

Navigate the the global IGMP prompt and enter:

ignore-nonlocal-report *action*

action is one of the following:

ignore (default)
accept

For example, the following command causes IGMP to accept join and leave messages from nonlocal networks:

```
igmp# ignore-nonlocal-report accept
igmp#
```

Using Site Manager

.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **NonLocal Reports parameter**. Site Manager: Forward Cache Limit parameter: page A-17	
6. Click on **Save**.	You return to the Configuration Manager window.

Customizing IGMP on an Interface

When you add a multicast protocol to an IP interface, IGMP is enabled with default values for all interface parameters. You customize IGMP on the interface by modifying these parameters as described under the following topics:

Topic	Page
Enabling and Disabling IGMP on an Interface	3-14
Specifying a Query Rate	3-15
Specifying a Membership Timeout Interval	3-17
Specifying a Designated Router Timeout Interval	3-18
Specifying a Maximum Host Response Time	3-19
Specifying the Lifetime of a Cache Entry for Mtrace	3-20

Enabling and Disabling IGMP on an Interface

When you add a multicasting protocol to an IP interface, IGMP is automatically enabled on the interface.

Note: IGMP is required for multicasting to function on the interface.

You can use the BCC or Site Manager to disable and reenable IGMP on the interface

Using the BCC

Navigate to the IGMP prompt for the interface and enter:

state *state*

state is one of the following:

enabled
disabled

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Entry**.	The IGMP Entry Interface Parameters window opens.
5. Set the **Enable** parameter. Site Manager: Enable parameter: page A-20	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Specifying a Query Rate

By default, IGMP sends a group membership query on the interface every 120 seconds.

Specifying zero disables queries only. The router still forwards multicast datagrams on this circuit.

Note: If another IGMP router on this network has taken on the query role, this router will not send out queries unless it has not heard of any queries within the number of seconds specified by the Designated Router Timeout parameter.

You can use the BCC or Site Manager to disable queries or specify a query rate from 0 to 4096 seconds.

Using the BCC

Navigate the IGMP prompt for the interface and enter:

query-rate *rate*

rate is the number of seconds from 0 (disabling queries) to 4096.

For example, the following command specifies a query rate of 300 seconds:

```
igmp/2.2.2.2/3# query-rate 300
igmp/2.2.2.2/3#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Entry**.	The IGMP Entry Interface Parameters window opens.
5. Set the **Interface Query Rate** parameter. Site Manager: Interface Query Rate parameter: page A-20	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Specifying a Membership Timeout Interval

By default, a local group membership is valid for 260 seconds without the receipt of a subsequent report for that group.

You can use the BCC or Site Manager to specify an interval from 50 to 8192 seconds.

Using the BCC

Navigate to the IGMP prompt for the interface and enter:

membership-timeout *seconds*

seconds is a period from 50 to 8192 seconds.

For example, the following command specifies a membership timeout period of 300 seconds:

```
igmp/2.2.2.2/3# membership-timeout 300
igmp/2.2.2.2/3#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Entry**.	The IGMP Entry Interface Parameters window opens.
5. Set the **Interface Membership Timeout** parameter. Site Manager: Interface Membership Timeout parameter: page A-20	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Specifying a Designated Router Timeout Interval

By default, 140 seconds can elapse after the last host query message before IGMP considers the designated router to be down.

The value you specify should be greater than the query rate of all IGMP routers on the network. The suggested value is (2 * Query Rate) + 20.

You can use the BCC or Site Manager to specify a timeout interval from 10 to 8192 seconds.

Using the BCC

Navigate to the IGMP prompt for the interface and enter:

dr-timeout *seconds*

seconds is an interval from 10 to 8192 seconds.

For example, the following command sets the timeout interval to 200 seconds:

```
igmp/2.2.2.2/3# dr-timeout 200
igmp/2.2.2.2/3#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Entry**.	The IGMP Entry Interface Parameters window opens.
5. Set the **Designated Router Timeout** parameter. Site Manager: Designated Router Timeout parameter: page A-21	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Specifying a Maximum Host Response Time

By default, a host must wait 100 tenths of a second before responding to a query. IGMP places this value in the code field of an IGMP query.

You can use the BCC or Site Manager to specify a value from one tenth of a second to 100 tenths of a second.

Using the BCC

Navigate to the IGMP prompt for the interface and enter:

max-host-response *time*

time is an integer from 1 to 100 specifying the response time in tenths of a second.

For example, the following command sets the host response to 25 tenths of a second:

```
igmp/2.2.2.2/3# max-host-response 25
igmp/2.2.2.2/3#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Entry**.	The IGMP Entry Interface Parameters window opens.
5. Set the **Max Host Response Time** parameter. Site Manager: Max Host Response Time parameter: page A-21	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Specifying the Lifetime of a Cache Entry for Mtrace

IGMP creates entries in the forwarding cache specifically for the Mtrace utility. By default, IGMP keeps these entries in the forwarding cache for a maximum of 30 seconds.

You can use the BCC or Site Manager to specify a different lifetime value from 30 to 8192 seconds.

Using the BCC

Navigate to the IGMP prompt for the interface and enter:

mtrace-lifetime *seconds*

seconds is an integer from 30 to 8192 seconds.

For example, the following command sets the Mtrace cache entry lifetime to 60 seconds:

```
igmp/2.2.2.2/3# mtrace-lifetime 60
igmp/2.2.2.2/3#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **Multicast**.	The Multicast menu opens.
4. Choose **IGMP**.	The IGMP menu opens.
5. Choose **Entry**.	The IGMP Entry Interface Parameters window opens.
6. Set the **Mtrace Entry Lifetime** parameter. Site Manager: Mtrace Entry Lifetime parameter: page A-21	
7. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Configuring a Static Host Entry

A network may include a member of a multicast group that is unable to register its group membership with the local IGMP router, for example, a host that is a member of a multicast group but that is not running IGMP.

In this situation, you can register the group member's network statically on the router.

A registration entry includes:

- A group address
- An address prefix length
- A circuit name

You can use Site Manager to supply this information.

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Static Groups**.	The IP IGMP Static Groups window opens.
5. Set the following parameters: • **Group Address** • **Prefix Length** • **Circuit Name** Click on **Help** or see the parameter descriptions beginning on page A-19.	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Configuring an IGMP Boundary Group

You configure an IGMP boundary group by supplying a range of multicast group addresses (expressed as an address and a prefix) and a list of IP interfaces. No multicast group address that falls within the range you specify is accepted or forwarded on the interfaces you specify.

You can use Site Manager to define an IGMP boundary group.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Boundaries**.	The IP Boundary Group window opens.
5. Set the following parameters: • **Enable** • **Group Address** • **Prefix Length** • **Circuit List** • **Tunnel List** Click on **Help** or see the parameter descriptions beginning on page A-51.	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Configuring IGMP Policies

Site Manager allows you to create IGMP group pollicies and IGMP Static Forwarding Entry policies.

Use the following procedure to create IGMP group policies:

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **Policies.**	The IP Policies menu opens.
4. Choose IGMP**.**	The IGMP Policies menu opens.
5. Chose **IGMP Group Policy Filters.**	The IGMP Group Policy Filters window opens.
6. Set the the following parameters: • **Name** • **Sources** • **Action** • **Precedence** • **Group** • **Circuits** • **Senders** Click on **Help** or see the parameter descriptions starting on page A-44.	
7. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Use the following procedure to configure IGMP Static Forwarding Entry policies:

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **Policies.**	The IP Policies menu opens.
4. Choose **IGMP.**	The IGMP Policies menu opens.
5. Chose **IGMP Static Forwarding Entry**.	The IGMP Static Forwarding Entry window opens.
6. Set the the following parameters: • **Name** • **Groups** • **Preference** • **Precedence** • **Sources** • **In Circuits** • **Out Circuits** Click on **Help** or see the parameter descriptions starting on page A-48.	
7. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Chapter 4
Customizing DVMRP

This chapter describes the Distance Vector Multicast Routing Protocol (DVMRP).

Topic	Page
DVMRP Concepts and Terminology	4-2
Customizing DVMRP Globally	4-8
Customizing DVMRP on a Circuit	4-22
Configuring a Tunnel	4-33
Configuring DVMRP Announce Policies	4-45

DVMRP Concepts and Terminology

DVMRP is a multicasting protocol that provides a mechanism for routers to propagate multicast datagrams in a manner that minimizes the number of excess copies sent to any particular network.

This section covers the following topics:

Topic	Page
Neighbor Connections	4-2
Source Route Advertisements	4-4
How DVMRP Chooses a Route	4-5
Routing Table	4-6
Shortest-Path Trees	4-7

Neighbor Connections

In a DVMRP environment, *neighbors* are multicasting routers that are connected directly or through a tunnel:

- *Directly connected neighbors* are routers that have an interface to the same network.
- *Tunnel-connected neighbors* are multicast routers that communicate through a unicast network, exchanging DVRMP messages that are encapsulated in IP datagrams.

In Figure 4-1, for example, multicasting router A has two neighbors, router B and router C. Router A and router B are connected directly -- they both have interfaces to net 6. router A and router C communicate through a tunnel that includes a unicast router.



Figure 4-1. Multicast Routers

At startup, a DVMRP multicasting router:

1. Initializes its routing table with information on all of its local networks
2. Learns the existence of its neighbors by sending a probe for all routes on each of its multicast interfaces (both physical circuits and tunnels)
3. Receives reports from its neighbors containing the routing information (including route costs)

In Figure 4-1, for example, router D becomes active and issues routing probes on four multicasting interfaces. router D receives reports from its multicasting neighbors, routers B, C, and E.

Source Route Advertisements

A *source network* is any network containing hosts that have the capability to issue multicast datagrams. DVMRP advertises shortest-path routes to multicasting source networks. In this respect, DVMRP is the opposite of RIP, which advertises routes to destination networks.

Periodically, each multicasting router issues full or partial routing information on each DVMRP circuit, using DVMRP report messages. This routing information represents the sending router's cost to reach the specified source network. (The cost is the sum of the hop metrics along the shortest path to the given source network.)

Upon receiving a DVMRP report from another router, DVMRP reexamines its routing table to determine if the shortest path information needs updating. Specifically, DVMRP looks in the routing table for an entry describing a route to the same source network. If one exists, DVMRP compares the cost of the two routes and stores the route with the lower cost in its routing table.

A router will not send route reports on an interface until it knows (by means of received probes or reports) that it has a neighboring multicast router on that interface. It will continue to send probes periodically on an interface.

How DVMRP Chooses a Route

Each DVMRP interface is configured with a metric that indicates the cost of the hop. A router that receives multiple route reports for the same multicasting source network:

- Compares the cost specified in each (based on the metric field)
- Stores information from the report with the lowest cost in its routing table

A route metric is the sum of all the interface (hop) metrics from a given route source to a given router.

In Figure 4-1 on page 4-3, for example, router D receives two reports for the network connected to multicasting router A, one from router B and one from router C. Using the metrics contained in the route reports, router D determines that the cost of the tunneled route is greater than the cost of the route that uses direct physical connections. Router D discards the route received from router C and stores the route received from router B.

Router D then declares router B to be the next-hop neighbor and interface d1 to be the next-hop interface. After a next-hop neighbor has been declared for a route, the route updates received from that neighbor for that route take precedence until either the route times out or until another router advertises a better metric for that route.

Routing Table

Table 4-1 shows the principal items in a routing table entry.

Table 4-1. Parts of a Routing Table Entry

Item	Description
Source subnet address and mask	Address and mask of a subnetwork containing a host sourcing multicast datagrams
From-gateway	Previous-hop router leading back to the source subnet
TTL	Number of seconds before this entry is removed from the routing table

Note that the source subnet and the previous-hop router in the DVMRP routing table are the opposite of the destination subnet and next-hop router in a RIP routing table.

Using this information, the router can:

1. Receive a multicast datagram and determine if the datagram has arrived on the interface that is on the shortest path to the source network.
2. Drop the datagram if it has not arrived on the shortest-path interface.
3. Flood the multicast datagram to all active downstream DVMRP neighbors.

Shortest-Path Trees

Route information used by DVMRP is independent of any other routing information used by the router -- for example, routes provided by RIP. The purpose of this routing information is to create a shortest-path tree entry in the routing table for the propagation of multicast datagrams.

The shortest-path tree entry indicates the interface that provides the shortest path to the network that is the source of the multicast datagram.

In Figure 4-1 on page 4-3, for example, the routing table on router D includes an entry describing the shortest-path route to the network connected to router A. The entry indicates that Interface d1 provides the shortest path to that source network.

A shortest-path tree also indicates those interfaces that are on the shortest path to that source network from a neighboring router.

Router E considers the network connecting it to router D to be on the shortest path to the source network connected to router A. Router D has an interface (d3) that is part of the shortest path from router E from the network connected to router A.

If neighboring routers have the same metric to a given source network, the router with the lower IP address is responsible for propagating multicast traffic originating from that source network onto the network or tunnel that is common to these neighboring routers.

A network is considered a leaf network if it has no dependent downstream neighbors for a source. In Figure 4-1, the network connected to router E (net 5) is a *leaf network.*

Customizing DVMRP Globally

When you start DVMRP on the router, DVMRP runs with default values for all global protocols. You customize DVMRP by modifying parameters as described under the following topics:

Topic	Page
Disabling and Reenabling DVMRP	4-9
Setting the Update Interval	4-10
Configuring Tree Pruning	4-11
Configuring DVMRP Timers	4-12
Specifying a Probe Interval	4-16
Specifying a Route Switch Interval	4-17
Estimating the Number of Routes	4-18
Logging Debugging Messages	4-19
Specifying the Maximum Number of Routes	4-20
Enabling and Disabling Routing Policies	4-21

Disabling and Reenabling DVMRP

You can use Site Manager to disable and reenable DVMRP on the router.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Enable** parameter. Site Manager: Enable parameter: page A-2	
6. Click on **Save**.	You return to the Configuration Manager window.

Setting the Update Interval

Periodically, each multicasting router issues full or partial routing information on each DVMRP circuit, using DVMRP report messages. This routing information represents the sending router's cost to reach the specified network. (The cost is the sum of the hop metrics along the shortest path to the given source network.)

You can use Site Manager to:

- Specify how often routing messages containing complete routing tables are sent.
- Specify the minimum amount of time between *triggered updates*. Triggered updates are sent when routing information changes. Issuing a full update restarts the triggered update timer. Therefore, the triggered update interval you specify must be shorter than the full update interval you set.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the following parameters: • **Full Update Interval** • **Triggered Update Interval** Click on **Help** or see the parameter descriptions beginning on page A-2.	
6. Click on **Save**.	You return to the Configuration Manager window.

Configuring Tree Pruning

If no members are detected on a branch of the shortest path tree for a given group, DVMRP *prunes* the branch.

The following conditions cause DVMRP to prune the shortest-path tree for a given group:

- The router determines that the attached network on which the host is located (or any other locally attached network) has no active member of the group.
- The router determines that all neighbors on all attached networks other than the next-hop network to the source have pruned off the source and group.
- The router determines that it is not located on the shortest network path to any remote network that includes a member of the group.
- The router sends a DVMRP prune message to its DVMRP neighbor. The neighbor removes the router from its forwarding table.

  If the host later rejoins the group, the router sends the neighbor a DVMRP graft message. The neighbor restores the router to its forwarding table.

Tree pruning is enabled on the router by default. You can use Site Manager to disable and reenable tree pruning on the router.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Pruning Enable** parameter. Site Manager: Pruning Enable parameter: page A-6	
6. Click on **Save**.	You return to the Configuration Manager window.

Configuring DVMRP Timers

When a router adds or updates a route, it uses configurable timers to control the useful life of the route.

Note: DVMRP timers must be the same throughout the network.

Setting the Route Expiration Timer

The route expiration timer determines how long DVMRP waits for an update message indicating that a route is reachable. Upon expiration of this timer, this route is advertised as unreachable until it is refreshed or until it is garbaged.

By default, DVMRP sets the route expiration time at 200 seconds.You can use Site Manager to set the route expiration time from 20 to 4000 seconds.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Route Expiration Timeout** parameter. Site Manager: Route Expiration Timeout parameter: page A-3	
6. Click on **Save**.	You return to the Configuration Manager window.

Setting the Garbage Timer

The garbage timer determines how long DVMRP advertises a route as unreachable before it removes the route from the routing table. The difference between this value and the route expiration timeout value represents the time period that the route will be advertised as unreachable without subsequent refreshment.

By default, DVMRP sets the garbage timer to 340 seconds. You can use Site Manager to set the value from 40 to 8000 seconds.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Garbage Timeout** parameter. Site Manager: Garbage Timeout parameter: page A-4	
6. Click on **Save**.	You return to the Configuration Manager window.

Enter a value that is greater than the value you specified for the route expiration timer to allow enough time for the route to be advertised as unreachable.

Setting the Neighbor Report Timer

The neighbor report timer specifies how long the router waits to receive a report from a neighbor before considering the connection inactive.

By default, DVMRP waits 140 seconds. You can use Site Manager to specify a value from 40 to 8000 seconds.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Neighbor Timeout** parameter. Site Manager: Neighbor Timeout parameter: page A-3	
6. Click on **Save**.	You return to the Configuration Manager window.

Setting the Leaf Timer

The leaf timer determines whether or not a network or tunnel local to a given interface is considered to be part of the shortest path to a given source network by any DVMRP neighbor.

If during this time the local interface has not received a route report for a given source network, this network or tunnel and its local interface are considered not to lie in the shortest path for any neighbor. In other words, the local network is not part of the shortest path to that specific source network.

By default, DVMRP sets the leaf timer at 200 seconds. You can use Site Manager to specify a value from 25 to 4000 seconds.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Leaf Timeout** parameter. Site Manager: Leaf Timeout parameter: page A-3	
6. Click on **Save**.	You return to the Configuration Manager window.

Specifying a Probe Interval

The probe interval determines how often DVMRP sends a probe on interfaces from which no neighbors have been heard.

By default, DVMRP sends a probe every 10 seconds. You can use Site Manager to specify a value from 5 to 30 seconds.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Neighbor Probe Interval** parameter. Site Manager: Neighbor Probe Interval parameter: page A-5	
6. Click on **Save**.	You return to the Configuration Manager window.

If your neighbor is running DVMRP *mrouted*, ensure that your probe interval value matches the value used by the neighbor.

Specifying a Route Switch Interval

The route switch interval specifies how long the router should wait, without receiving a subsequent route update from the original neighbor, before switching to a different neighbor advertising equal cost for this route.

By default, DVMRP waits 140 seconds. You can use Site Manager to specify a value from 20 to 2000 seconds.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Route Switch Timeout** parameter. Site Manager: Route Switch Timeout parameter: page A-5	
6. Click on **Save**.	You return to the Configuration Manager window.

If your neighbor is running DVMRP *mrouted*, the recommended value is 140 seconds.

Estimating the Number of Routes

By default, DVMRP preallocates a routing table for 25 entries. You can use Site Manager to specify the number of entries (10 or more).

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Estimated Routes** parameter. Site Manager: Estimated Routes parameter: page A-4	
6. Click on **Save**.	You return to the Configuration Manager window.

Enter a value that the router can use for preallocating routing tables. For an MBone implementation, a value of 3000 or higher is recommended.

Note that routes are kept on a per-source-network basis, independent of multicast groups. This number must include a route for every network that is local to a circuit configured for multicasting. This allows the router to utilize memory efficiently. Exceeding this size during router operation will not cause an error but may cause the router to consume more memory than required.

Logging Debugging Messages

By default, DVMRP does not log debugging messages. You can use Site Manager to enable the logging of debugging messages and to specify the level of debug messages.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Debug Level** parameter. Site Manager: Debug Level parameter: page A-5	
6. Click on **Save**.	You return to the Configuration Manager window.

Specifying the Maximum Number of Routes

By default, DVMRP stores all learned routes in the routing table. You can use Site Manager to specify the number of routes that DVMRP can learn per slot. This parameter limits the number of routes that can be stored in the routing table.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Max Routes** parameter. Site Manager: Max Routes parameter: page A-6	
6. Click on **Save**.	You return to the Configuration Manager window.

If you specify a maximum number of routes, you must include a route for every local network that has a circuit configured for multicasting.

Enabling and Disabling Routing Policies

By default, routing policies are globally disabled.

This parameter allows you to configure a policy for the specified route. Bay Networks currently supports only the policies that do not advertise the specified route or route range. Bay Networks supports policies that advertise a default route for the specified route or route range.

You can use the following Site Manager procedure to enable and disable routing policies as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Global**.	The DVMRP Global Configuration window opens.
5. Set the **Policy Enable** parameter. Site Manager: Policy Enable parameter: page A-6	
6. Click on **Save**.	You return to the Configuration Manager window.

Customizing DVMRP on a Circuit

You customize DVMRP on a circuit by modifying DVMRP parameters as described under the following topics:

Topic	Page
Disabling and Reenabling DVMRP on a Circuit	4-22
Disabling Multicast Support on a Unicast Tunnel	4-23
Calculating a Route Metric and Comparing Route Costs	4-24
Specifying a Threshold	4-25
Configuring a Forwarding Table	4-27
Disabling Advertisement of Local Networks	4-29
Advertising a Default Route	4-30
Listening for a Default Route	4-31
Accepting a Report from a Nonstandard DVMRP Neighbor	4-32

Disabling and Reenabling DVMRP on a Circuit

By default, DVMRP is enabled on a circuit. You can use Site Manager to disable and reenable it.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Enable** parameter. Site Manager: Enable parameter: page A-7	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Disabling Multicast Support on a Unicast Tunnel

By default, DVMRP:

- Propagates multicast routing information on the circuit
- Incorporates in routing updates information about the source network associated with this circuit
- Forwards multicast datagrams on this circuit in *native mode* -- that is, as multicast datagrams

Using Site Manager, you can disable multicast support on the circuit.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Route Enable** parameter. Site Manager: Route Enable parameter: page A-7	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Calculating a Route Metric and Comparing Route Costs

By default, a circuit has a cost of 1. Bay Networks recommends the following values:

Hop	Metric
LAN, or tunnel across a single LAN	1
Multihop tunnel	2 or 3
Serial link, or tunnel across a serial link	1
Backup tunnel	Primary tunnel metric + 1

You can use Site Manager to assign a cost from 1 to 31.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Metric** parameter. Site Manager: Metric parameter; page A-8	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Specifying a Threshold

Threshold values control the scope of datagram delivery. The threshold is the minimum IP TTL required for a multicast datagram to be forwarded out a given interface.

For *mrouted* compatibility, multicast datagrams originated by the router have a TTL of 1. These datagrams are not compared against the TTL. Unicast datagrams originated by the router (for example, for route reports issued via a tunnel) have a TTL of 255. A datagram that is to be forwarded through a tunnel is first compared against the threshold and, if accepted, is then encapsulated in an IP datagram with a TTL of 64.

Table 4-2 lists:

- Originating TTL values recommended for certain types of multicast applications
- Threshold values recommended for routers to permit the forwarding of packets from these applications

These values are recommended for topologies that will connect to the MBone.

Table 4-2. Recommended TTL and Threshold Values

Multicast Application	TTL	Threshold
IETF channel 1 low-rate GSM audio	255	224
IETF channel 2 low-rate GSM audio	223	192
IETF channel 1 PCM audio	191	160
IETF channel 2 PCM audio	159	128
IETF channel 1 video	127	96
IETF channel 2 video	95	64
Local event audio	63	32
Local event video	31	1

By default, DVMRP uses a TTL value of 1. You can use Site Manager to specify a TTL value from 1 to 254.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Threshold** parameter. Site Manager: Threshold parameter: page A-8	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Configuring a Forwarding Table

To minimize the amount of time that it spends looking up routes, DVMRP creates and maintains a cache of frequently used routes -- called a *forwarding table* -- for each IP interface.

By default, DVMRP preallocates a forwarding table of 32 entries for each circuit. You can use Site Manager to specify the maximum number of entries (32 to 512) allowed in the forwarding table associated with this circuit.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Forward Cache Size** parameter. Site Manager: Forward Cache Size parameter: page A-8	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

When configuring a cache size, you must also keep in mind the TTL value for entries. If you specify a large cache size, you can specify a larger TTL value. A smaller cache requires a smaller TTL for cache entries.

By default, DVMRP uses a TTL of 7200 seconds (two hours) for entries in the forwarding table. You can use Site Manager to specify a TTL from 300 to 86400 seconds.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Forward Cache TTL** parameter. Site Manager: Forward Cache TTL parameter: page A-9	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

If your neighbor is running *mrouted*, the recommended TTL value is 300 seconds.

Disabling Advertisement of Local Networks

By default, DVMRP advertises its own local networks over this circuit. Using Site Manager, you can configure DVMRP so that it does not advertise local networks over the circuit.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Advertise Self** parameter. Site Manager: Advertise Self parameter: page A-9	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Advertising a Default Route

By default, DVMRP does not supply a default route on this circuit.

You can use Site Manager to enable and disable this feature as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Route Supply** parameter. Site Manager: Route Supply parameter: page A-9	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Listening for a Default Route

By default, DVMRP does not listen for a default route on this circuit.

You can use Site Manager to enable and disable this feature as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Route Listen** parameter. Site Manager: Route Listen parameter: page A-10	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Accepting a Report from a Nonstandard DVMRP Neighbor

By default, DVMRP does not accept a report from a nonstandard DVMRP neighbor.

A standard DVMRP router does not advertise a route report before sending a probe message to a neighbor. DVMRP uses the probe message to learn the neighbor's capability. Some routers, however, send only route reports; they do not send probes. If you want DVMRP to communicate with nonstandard DVMRP routers, be sure to set the Route Depend Probe parameter to Enable.

You can use Site Manager to enable and disable this feature as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Circuit**.	The DVMRP Circuit Parameters window opens.
5. Set the **Route Depend Probe** parameter. Site Manager: Report Depend Probe parameter: page A-10	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Configuring a Tunnel

You configure a DVMRP tunnel by setting parameters as described under the following topics:

Topic	Page
Supplying Addresses for the Tunnel	4-34
Disabling and Reenabling the Tunnel	4-35
Choosing the Encapsulation Mode	4-36
Specifying the Cost	4-37
Specifying a TTL	4-38
Configuring a Forwarding Table for the Tunnel	4-39
Advertising a Default Route	4-41
Listening for a Default Route	4-42
Specifying an Encapsulation Mode for Control Messages	4-43
Accepting a Report from a Nonstandard DVMRP Neighbor	4-44

Supplying Addresses for the Tunnel

To identify a unicast tunnel, you must supply the unicast IP address of both ends of the tunnel: the local interface and the remote interface. You can use Site Manager to supply these addresses.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Click on **Add**.	The DVMRP Tunnel Address window opens.
6. Set the following parameters: • **Local IP Address** • **Remote IP Address** Click on **Help** or see the parameter descriptions beginning on page A-14.	
7. Click on **OK**.	You return to the DVMRP Tunnel Parameters window.

Disabling and Reenabling the Tunnel

When you configure a tunnel on a circuit, the tunnel is enabled by default. You can use Site Manager to disable and reenable the tunnel.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Enable** parameter. Site Manager: Enable parameter: page A-11	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Choosing the Encapsulation Mode

By default, DVMRP encapsulates a tunneled multicast datagram in an IP unicast datagram. Using Site Manager, you can configure DVMRP to loosely encapsulate multicast datagrams using the LSSR option.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Encapsulation Mode** parameter. Site Manager: Encapsulation Mode parameter: page A-11	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

See RFC 1075 for information about the LSSR option, which is provided for backward compatibility.

Specifying the Cost

By default, DVMRP assigns a metric of 1 to a tunnel. You can use Site Manager to specify a cost value from 1 to 31.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Metric** parameter. Site Manager: Metric parameter: page A-11	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Specifying a TTL

By default, DVMRP assigns a TTL value of 1 to a tunnel. This value is the minimum IP TTL required for a multicast datagram to be forwarded out this tunnel. You can use Site Manager to assign a value from 1 to 254.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Threshold** parameter. Site Manager: Threshold parameter: page A-12	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Use this value to control the scope of the datagrams. If the IP TTL is less than the threshold value you specify, the router drops the datagram.

Configuring a Forwarding Table for the Tunnel

By default, DVMRP preallocates a forwarding table for 32 entries. You can use Site Manager to specify the maximum number of entries (from 32 to 512) allowed in the forwarding table associated with this tunnel interface.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Forward Cache Size** parameter. Site Manager: Forward Cache Size parameter: page A-12	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

When configuring a cache size, you must also keep in mind the TTL value for entries. If you specify a large cache size, you can specify a larger TTL value. A smaller cache requires a smaller TTL for cache entries.

By default, DVMRP assigns a TTL value of 7200 seconds to an entry in a tunnel forwarding table. You can use Site Manager to assign a value from 300 to 86400 seconds.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Forward Cache TTL** parameter. Site Manager: Forward Cache TTL parameter: page A-12	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Advertising a Default Route

By default, DVMRP does not supply a default route on this tunnel.

You can use Site Manager to enable and disable this feature as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Route Supply** parameter. Site Manager: Route Supply parameter: page A-13	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Listening for a Default Route

By default, DVMRP does not listen for a default route on this tunnel.

You can use Site Manager to enable and disable this feature as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Route Listen** parameter. Site Manager: Route Listen parameter: page A-13	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Specifying an Encapsulation Mode for Control Messages

To maintain backward compatibility with earlier versions of DVMRP, DVMRP allows you configure the encapsulation mode for DVMRP control packets.

You can use the following Site Manager procedure to perform this operation.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Control Message Mode** parameter. Site Manager: Control Message Mode parameter: page A-13	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Accepting a Report from a Nonstandard DVMRP Neighbor

By default, DVMRP does not accept a report from a nonstandard DVMRP neighbor.

A standard DVMRP router does not advertise a route report before it has sent a probe message to a neighbor. DVMRP uses the probe message to learn the neighbor's capability. Some routers, however, send only route reports; they do not send probes. If you want DVMRP to communicate with nonstandard DVMRP routers, be sure to set the Route Depend Probe parameter to Enable.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **DVMRP**.	The DVMRP menu opens.
4. Choose **Tunnel**.	The DVMRP Tunnel Parameters window opens.
5. Set the **Report Depend Probe** parameter. Site Manager: Report Depend Probe parameter: page A-14	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Configuring DVMRP Announce Policies

Note: DVMRP does not support accept policies. DVMRP supports only the ignore action of announce policies.

A DVMRP announce policy governs the propogation of DMVRP routing information. Use the following Site Manager procedure to create a DVMRP announce policy.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **Policies.**	The IP Policies menu opens.
4. Choose **DVMRP**.	The DVMRP Announce IP Policy Filters window opens.
5. Set the the following parameters: • **Name** • **Networks** • **Action** • **Precedence** • **Advertise** • **Filtered Circuits** • **Filtered Tunnels** Click on **Help** or see parameter descriptions starting on page A-43.	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Chapter 5
Customizing OSPF Multicast Extensions

MOSPF is a multicasting extension of OSPF. You configure MOSPF by setting OSPF global parameters, interface parameters, and area parameters. This chapter covers the following topics:

Topic	Page
MOSPF Overview	5-2
Configuring MOSPF Globally	5-4
Configuring Multicast Forwarding on an OSPF Interface	5-10
Configuring Multicast-Capable External Routes	5-11
Configuring MOSPF Announce Policies	5-12

MOSPF Overview

MOSPF is a multicasting extension of the OSPF protocol that allows a router to forward multicast IP traffic within an OSPF Version 2 AS.

An OSPF environment typically consists of an AS divided into multiple areas connected by an OSPF backbone. You can configure an OSPF/MOSPF router as a:

- Multicasting *internal router* (IR) that establishes neighbor relationships with adjacent routers within an area
- Multicasting *border router* (BR) with interfaces to one or more areas and to the OSPF backbone
- Multicasting *boundary router* (ASBR) with one or more interfaces to external autonomous systems

Figure 5-1 shows an OSPF/MOSPF AS consisting of two OSPF areas connected by an OSPF backbone.



Figure 5-1. OSPF Autonomous Systems

MOSPF supports four types of multicasting:

- Intra-area multicasting for OSPF internal routers
- Intra-area and inter-area multicasting for OSPF border routers
- Intra-area and inter-AS multicasting for OSPF boundary routers
- All multicasting types

Configuring MOSPF Globally

Note: Bay Networks does not support dynamic configuration of MOSPF/QOSPF. After making local configuration changes, restart OSPF by disabling and reenabling it.

Note: If you enable MOSPF, do not run other multicasting protocols on any OSPF interfaces, even if MOSPF is disabled on those interfaces (that is, even if you set the Multicast Forwarding Parameter to blocked). If you want to disable MOSPF on a network, use Site Manager to disable MOSPF on all routers in the network.

Note: If you are configuring an OSPF network with both MOSPF and non-MOSPF, set the non-MOSPF routers to priority 0 so that the MOSPF routers can become designated router and backup designated router (DR/BDR), which is necessary for MOSPF to work.

You can use Site Manager to add MOSPF extensions to OSPF.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Global**.	The Edit OSPF Global Parameters window opens.
5. Set the **Multicast Extensions** parameter. Site Manager: Multicast Extensions parameter: page A-31	
6. Click on **OK**.	You return to the Configuration Manager window.

After you configure OSPF with multicast extensions, you can set multicast global parameters as described under the following topics:

Topic	Page
Enabling Deterministic Multicasting	5-6
Specifying a Forwarding Timeout Value	5-7
Specifying a Maximum Number of Queued Packets	5-8
Enabling Dynamic TTL	5-9

Note: MOSPF will not forward datagrams out an interface until multicast forwarding is enabled on the interface. For instructions, refer to “Configuring Multicast Forwarding on an OSPF Interface” on page 5-10.

Enabling Deterministic Multicasting

MOSPF runs in two modes:

- In *nondeterministic mode*, MOSPF selects paths with the lowest metric cost.
- In *deterministic mode*, MOSPF uses OSPF quality of service extensions (called QOSPF) to choose paths that provide the requested QoS.

By default, deterministic MOSPF is disabled. You can use Site Manager to enable deterministic MOSPF globally.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Global**.	The Edit OSPF Global Parameters window opens.
5. Set the **Multicast Deterministic** parameter. Site Manager: Multicast Deterministic parameter: page A-31	
6. Click on **OK**.	You return to the Configuration Manager window.

When you choose MOSPF deterministic mode, you are enabling OSPF with default values for all QOSPF parameters. You customize QOSPF by modifying OSPF parameters as described in Chapter 6.

Specifying a Forwarding Timeout Value

You can use Site Manager to specify a value for timing out MOSPF entries in the forwarding table.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Global**.	The Edit OSPF Global Parameters window opens.
5. Set the **Timeout Value** parameter. Site Manager: Timeout Value parameter: page A-32	
6. Click on **OK**.	You return to the Configuration Manager window.

Specifying a Maximum Number of Queued Packets

By default, MOSPF queues a maximum of 64 packets per slot for all dataflows.

You can control how many multicast packets can be queued on each slot for all flows before MOSPF finishes building multicast trees.

If you disable queuing, packets are dropped before the tree is calculated.

If you specify a maximum value, the first few data packets for a multicast flow are queued before MOSPF finishes building the multicast tree.

You can use the following Site Manager procedure to disable queuing or specify a different maximum number of queued packets.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Global**.	The Edit OSPF Global Parameters window opens.
5. Set the **Max Queued Multcast Pkts** parameter. Site Manager: Max Queued Multcast Packets parameter: page A-33	
6. Click on **OK**.	You return to the Configuration Manager window.

Enabling Dynamic TTL

You can configure MOSPF to drop multicast packets that do not have a TTL high enough to reach the closest group member.

By default, this feature is disabled.

You can use the following Site Manager procedure to enable and disable the feature as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Global**.	The Edit OSPF Global Parameters window opens.
5. Set the **Dynamic TTL** parameter. Site Manager: Dynamic TTL parameter: page A-33	
6. Click on **OK**.	You return to the Configuration Manager window.

Configuring Multicast Forwarding on an OSPF Interface

By default, multicast packets are forwarded on an OSPF interface. You can use Site Manager to configure OSPF forwarding on the interface as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Interfaces**.	The Edit OSPF Interfaces window opens.
5. Set the **Multicast Forwarding** parameter. Site Manager: Multicast Forwarding parameter: page A-34	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Configuring Multicast-Capable External Routes

By default, all external routes are multicast incapable. The Multicast Downstream IGMP Relay parameter allows you to configure an external route as multicast capable.

If an MOSPF router works as an AS boundary router to support IGMP Relay, you must use Site Manager to set this attribute to Enabled.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Global**.	The Edit OSPF Global Parameters window opens.
5. Set the **Multicast Downstream IGMP Relay** parameter. Site Manager: Multicast Downstream IGMP Relay parameter: page A-34	
6. Click on **OK**.	You return to the Configuration Manager window.

Configuring MOSPF Announce Policies

Note: MOSPF does not support MOSPF accept policies. Use the MOSPF announce route policy to import DVMRP routes as multicast ASE routes. When connecting an MOSPF domain to an Mbone implementation via DVMRP, keep the OSPF database small by configuring an MOSPF announce policy to import only the default DVMRP route to the MOSPF domain.

Use the following Site Manager procedure to create an MOSPF announce policy:

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **Policies**	The IP Policies menu opens.
4. Choose **MOSPF**.	The MOSPF Announce IP Policy Filters window opens.
5. Set the the following parameters: • **Name** • **Networks** • **Action** • **Precedence** • **Advertise** Click on **Help** or see the parameter descriptions starting on page A-39.	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Chapter 6
Configuring QOSPF

QOSPF is an extension of OSPF that works in conjunction with RSVP to provide quality of service for multicast data flows.

For OSPF, the best path is the path with the least metric cost. OSPF does not consider network resource information when it selects the best path to a destination.

With QOSPF extensions added, OSPF/MOSPF calculates QoS routes that can provide the best resources for a multicast flow even though the route may not be the path with the least metric cost.

In Figure 6-1, for example, host 3 (H3) on network 2 wants to send multicast data at rate R to a group whose members (H1 and H2) reside on network 1. Without QOSPF extensions, MOSPF in router 3 forwards the data to router 1 (using the interface with lowest metric cost), whether or not router 1 has the resources to transmit data at rate R.

Now assume that router 2 has the resources to transmit data at rate R and router 1 does not. With QOSPF enabled on all routers, OSPF forwards the data to router 2, even though the interface has a higher metric cost.



Figure 6-1. QOSPF Topology

You add QOSPF extensions to OSPF by enabling MOSPF in deterministic mode as described in “Enabling Deterministic Multicasting” on page 5-6.

When you select deterministic mode, QOSPF runs with default values for global and interface parameters. You customize QOSPF by modifying these parameters as described under the following topics:

Topic	Page
Enabling the Deterministic Holddown Feature	6-3
Enabling Route Pinning	6-4
Enabling the Opaque Capability	6-5
Enabling the Opaque Capability on an Interface	6-6

Enabling the Deterministic Holddown Feature

The deterministic holddown feature ensures that a data flow does not go out an interface unless there is a reservation for the flow on the interface.

By default the holddown feature is disabled. You can use Site Manager to enable this feature.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Global**.	The Edit OSPF Global Parameters window opens.
5. Set the **Deterministic Mcast Hold Down** parameter. Site Manager: Deterministic Mcast Hold Down parameter: page A-32	
6. Click on **OK**.	You return to the Configuration Manager window.

Enabling Route Pinning

Route pinning ensures that once resource reservations have been established on a route from a source network to a particular receiver, the router will not replace that route with a better route (unless the established route is no longer usable).

By default, route pinning is disabled. If you have enabled MOSPF globally, you can use Site Manager to enable route pinning.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Global**.	The Edit OSPF Global Parameters window opens.
5. Set the **Multicast Route Pinning** parameter. Site Manager: Multicast Route Pinning parameter: page A-31	
6. Click on **OK**.	You return to the Configuration Manager window.

Enabling the Opaque Capability

The OSPF opaque capability provides support for additional types of LSAs and additional extensions. QOSPF requires the opaque capability.

By default, the opaque capability is disabled.

You can use Site Manager to enable and disable this feature globally as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Global**.	The Edit OSPF Global Parameters window opens.
5. Set the **Opaque Capability** parameter. Site Manager: Opaque Capability parameter: page A-32	
6. Click on **OK**.	You return to the Configuration Manager window.

Enabling the Opaque Capability on an Interface

By default, if you have enabled the OSPF opaque capability globally, the feature is turned on for each OSPF interface. You can use Site Manager to set the state of the opaque capability as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **OSPF**.	The OSPF menu opens.
4. Choose **Interfaces**.	The Edit OSPF Interfaces window opens.
5. Set the **Opaque On** parameter. Site Manager: Opaque On parameter: page A-35	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Chapter 7
Configuring RSVP

The Resource Reservation Protocol (RSVP) allows host systems in an IP network to reserve resources on RSVP-capable routers for:

- Unicast dataflows
- Multicast dataflows

(A dataflow is a transmission of packets from a source to one or more destinations requiring a specific QoS.)

This chapter covers the following topics:

Topic	Page
How RSVP Works	7-2
Configuring RSVP Globally	7-4
Configuring RSVP on an Interface	7-7

How RSVP Works

A network host that wants to establish a dataflow with a specified QoS sends an RSVP path message addressed to a potential receiving host or group of hosts. In Figure 7-1, for example, a host sends a multicast RSVP path message to a group of four hosts. Routers in the network receive the multicast RSVP messages and forward them to the next-hop router until the messages reach their host destinations. The sequence of networks and routers that a path message traverses from source to destination establishes the path for the proposed dataflow.



Figure 7-1. RSVP Path Message

A network host that receives an RSVP path message decides whether it wants to receive data on the proposed dataflow. If so, the host returns an RSVP reserve message. In Figure 7-2, for example, each host that has received an RSVP path message returns a reserve message. Each router in the network:

1. Passes the reservation request to the local Circuit Resource Manager (CRM).
2. Forwards the reservation request to the previous hop in the flow (as determined by the earlier path message).

In this manner, the reserve message traces the data path set up by the corresponding path message and establishes resource reservation along the data path at each router. Note that reservations from multiple receivers may be merged on their way to the sender of the path message.



Figure 7-2. RSVP Reserve Message

Configuring RSVP Globally

When you start RSVP on the router, RSVP runs with default values for all global protocols. You customize RSVP by modifying parameters as described under the following topics:

Topic	Page
Disabling and Reenabling RSVP	7-4
Choosing a Slot	7-5
Configuring RSVP Message Logging	7-6

Disabling and Reenabling RSVP

By default, RSVP is enabled on the router.

You can use Site Manager to set the global state of RSVP as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Global**.	The RSVP Base Group Record window opens.
4. Set the **Enable** parameter. Site Manager: Enable parameter: page A-35	
5. Click on **Save**.	You return to the Configuration Manager window.

Choosing a Slot

By default, RSVP runs on every slot where it is configured.

You can use Site Manger to specify the slot or slots on which you want RSVP to run.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Global**.	The RSVP Base Group Record window opens.
4. Set the **Soloist Slots** parameter. Site Manager: Soloist Slots parameter: page A-35	
5. Click on **Save**.	You return to the Configuration Manager window.

Configuring RSVP Message Logging

You can use Site Manager to specify the messages you want to log.

Caution: Enabling message logging increases the chance of losing information because of lack of memory.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Global**.	The RSVP Base Group Record window opens.
4. Set the **Log Filter** parameter. Site Manager: Log Filter parameter: page A-36	
5. Click on **Save**.	You return to the Configuration Manager window.

Configuring RSVP on an Interface

When you add RSVP to an IP interface, RSVP is configured on the interface with default values for all interface parameters. You customize RSVP on the interface by setting interface parameters as described under the following topics:

Topic	Page
Disabling and Reenabling RSVP on an Interface	7-7
Setting the RSVP Default Refresh Timer	7-8
Setting the RSVP Default Lifetime Multiplier	7-9
Setting the RSVP Refresh Blockade Multiplier	7-10
Setting the TTL Override	7-11
Setting the Route Delay Value	7-12
Enabling and Disabling UDP Encapsulation	7-13

Disabling and Reenabling RSVP on an Interface

By default, RSVP is enabled on every interface on which it is configured. You can use Site Manager to change the state of RSVP on an interface as required.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Circuit**.	The Edit RSVP Circuit Parameters window opens.
4. Set the **Enable** parameter. Site Manager: Enable parameter: page A-37	
5. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Setting the RSVP Default Refresh Timer

RSVP sends periodic refresh messages to maintain the state along a reserved path. Without periodic refreshment, the state automatically times out.

The refresh timer interval is expressed in hundredths of a second. By default, the RSVP Refresh Timer is set to 3000 hundredths of a second (30 seconds).

You can use Site Manager to set the Refresh Timer for an interface. You must express the interval in hundredths of a second.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Circuit.**	The Edit RSVP Circuit Parameters window opens.
4. Set the **Refresh Interval** parameter. Site Manager: Refresh Interval parameter: page A-38	
5. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Setting the RSVP Default Lifetime Multiplier

The Lifetime Multiplier is an integer that multiplies the TIME_VALUE object specified in a path or reserve message. The resulting value indicates the amount of time that the router will hold the path or reserve state without receiving a refresh message for that state.

By default, the Lifetime Multiplier is 3. You can use Site Manager to specify a multiplier.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Circuit**.	The Edit RSVP Circuit Parameters window opens.
4. Set the **Refresh Multiple** parameter. Site Manager: Refresh Multiple parameter: page A-37	
5. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Setting the RSVP Refresh Blockade Multiplier

By default, an RSVP interface in the blockade state will stay alive for three refresh intervals.

You can use Site Manager to set the refresh blockade multiplier.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Circuit**.	The Edit RSVP Circuit Parameters window opens.
4. Set the **Refresh Blockade Multiple** parameter. Site Manager: Refresh Blockade Multiple parameter: page A-37	
5. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Setting the TTL Override

By default, RSVP uses the IP TTL value. You can use Site Manager to override this value.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Circuit**.	The Edit RSVP Circuit Parameters window opens.
4. Set the **TTL** parameter. Site Manager: TTL parameter: page A-38	
5. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Setting the Route Delay Value

The route delay value specifies the approximate period that elapses between the time a route is changed to the time a resulting message appears on the interface.

The route delay is expressed in hundredths of a second. By default, the route delay is 200 hundredths of a second (2 seconds). You can use Site Manager to specify a different delay. You must express the delay in hundredths of a second.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Circuit**.	The Edit RSVP Circuit Parameters window opens.
4. Set the **Route Delay** parameter. Site Manager: Route Delay parameter: page A-38	
5. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Enabling and Disabling UDP Encapsulation

By default, RSVP uses UDP encapsulation on this interface only if it determines that a neighbor on the interface uses UDP encapsulation. Enable this feature on the interface if manual configuration requires UDP encapsulation.

You can use Site Manager to enable and disable UDP encapsulation on the interface.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **RSVP Circuit**.	The Edit RSVP Circuit Parameters window opens.
4. Set the **Udp Required** parameter. Site Manager: Udp Required parameter: page A-39	
5. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Chapter 8
Reserving Line Resources

This chapter covers the following topics:

Topic	Page
About Line Resource Reservation	8-2
How the Resource Manager Works with RSVP	8-3
Setting the Estimated Bandwidth	8-4
Setting the Reservable Bandwidth	8-5
Specifying the Traffic Queuing Algorithm	8-6
Specifying the LRM Policing Algorithm	8-7
Setting the Bandwidth Interval	8-8
Setting the Inflate Reservations Percentage	8-9
Specifying the Unreserved Policing Algorithm	8-10
Specifying the Unreserved Queue Length	8-11
Specifying the Multiline Select Algorithm	8-12
Setting the Multiline Threshold Bandwidth	8-13
Setting the Reservation Latency	8-14
Setting the Maximum Reservable Bandwidth for a Dataflow	8-15
Setting the Maximum Buffer Space for a Dataflow	8-16

About Line Resource Reservation

Emerging real-time multicast applications for digitized voice and video (such as multimedia conferencing and virtual reality) require a level of consistent network service that routers cannot meet using simple first-in-first-out (FIFO) queuing mechanisms. The existing best-effort delivery service of IP networks, where variable queuing delays and data loss due to congestion are acceptable, is not sufficient.

Resource reservation protocols such as RSVP address the requirements of delay-sensitive applications by distributing information among routers to achieve a guaranteed quality of service (QoS) for specific packet streams (flows).

By reserving bandwidth for QoS requests, a system of line resource reservation can meet the demands of real-time applications and maintain bandwidth for other traffic.

Bay Networks line resource reservation supports bandwidth guarantees only. It does not support delay guarantees.

Resource Manager

The Bay Networks Resource Manager lets you define a certain percentage of a line's bandwidth as *reservable*. Applications that require a guaranteed QoS can negotiate for the reservable bandwidth. When the router honors a reservation request, the Resource Manager allocates bandwidth from the reservable bandwidth, reducing the bandwidth available for other requests.

Supported Media

You must enable the Resource Manager on 10-Mb/s and 100-Mb/s Ethernet, FDDI, MCT1, HSSI, and synchronous interfaces that are configured with RSVP. The Resource Manager supports the following synchronous interface encapsulation methods:

- Point-to-Point Protocol (PPP)
- Bay Networks Standard
- FDDI
- 100 Mb/s Ethernet

Note: You cannot use line resource management on a line you configured for PPP multilink.

How the Resource Manager Works with RSVP

The exchange between RSVP and the Resource Manager consists of the following steps:

1. The router receives an RSVP reserve message. The reserve message includes a flow specification (*flowspec*) that indicates the resources needed to meet the QoS.
2. RSVP passes the flowspec to the Resource Manager.
3. The Resource Manager compares the requested resources with available reservable bandwidth. The Resource Manager determines reservable bandwidth from configured values described later in this chapter. It also accounts for any active reserved flows.
4. The Resource Manager either reserves the necessary services or refuses service.

Setting the Estimated Bandwidth

To activate resource reservation, specify a line and enter the portion of the line's bandwidth to make available for RSVP requests.

Enter an estimated total bandwidth for this line, from 0 to 214748364 b/s. To enable line resource management, enter a value greater than 0.

For point-to-point lines, you can usually enter the total line speed.

For an Ethernet line, you must estimate a value, because shared-media lines may not have all of the bandwidth available. Base the estimate on line statistics, the number of connected workstations, or other site-specific information.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Estimated Bandwidth** parameter. Site Manager: Estimated Bandwidth parameter: page A-25	
4. Click on **OK**.	You return to the Configuration Manager window.

Setting the Reservable Bandwidth

To enable RSVP reservable resources, specify the portion of this line's bandwidth to make available for RSVP requests for guaranteed service. The value can be any integer from 0 to 214748364 b/s, and must be less than the value of the Estimated Bandwidth parameter.

Caution: Never make all available bandwidth reservable. Leave at least 15 percent of bandwidth available for network management, routing protocols, and other best-effort traffic.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Reservable Bandwidth** parameter. Site Manager: Reservable Bandwidth parameter: page A-25	
4. Click on **OK**.	You return to the Configuration Manager window.

Specifying the Traffic Queuing Algorithm

By default, the Line Resource Manager (LRM) uses best-effort scheduling for all reserved traffic.

You can select a priority queuing algorithm to schedule reserved traffic ahead of unreserved traffic.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Traffic Queuing Algorithm** parameter. Site Manager: Traffic Queuing Algorithm parameter: page A-26	
4. Click on **OK**.	You return to the Configuration Manager window.

Specifying the LRM Policing Algorithm

By default, LRM does not check RSVP packets against the flowspec (policing). This assumes that an upstream router is policing traffic, or the applications generating the reserved traffic consistently adhere to the flowspec and do not require policing.

When using the leaky bucket policing algorithm for reserved traffic, LRM makes sure that all packets using reserved bandwidth follow the flowspec that appears in the reserve message. For the controlled load service, LRM attempts to carry any packets that do not adhere to the flowspec.

Note that leaky bucket policing requires additional processing by the router.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Policing Algorithm** parameter. Site Manager: Policing Algorithm parameter: page A-26	
4. Click on **OK**.	You return to the Configuration Manager window.

Setting the Bandwidth Interval

By default, LRM measures instantaneous bandwidth over a 10-second interval. If 10 seconds is not sufficient, you can specify a different bandwidth interval for this interface, from 1 to 214748364 seconds.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Bandwidth Interval (Secs)** parameter. Site Manager: Bandwidth Interval (Secs) parameter: page A-27	
4. Click on **OK**.	You return to the Configuration Manager window.

Setting the Inflate Reservations Percentage

By default, LRM does not add a safety tolerance to each RSVP reservation on a line. To inflate (or overallocate) reservations made on this line, enter a percent value to increase each bandwidth request.

Increase the value of this parameter if you notice that LRM is discarding packets because applications generating reserved traffic are exceeding their flowspecs.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Inflate Reservations Percentage** parameter. Site Manager: Inflate Reservations Percentage parameter: page A-27	
4. Click on **OK**.	You return to the Configuration Manager window.

Specifying the Unreserved Policing Algorithm

LRM uses one of two policing algorithms for unreserved traffic:

- *Queue limit* -- Restricts the number of buffers (packets) of unreserved traffic that LRM queues

  This method of policing enables unreserved traffic to use available reserved bandwidth.

Note: If you enable priority queuing for this line, the router uses the priority queue parameters to perform queue limit policing. See *Configuring Traffic Filters and Protocol Prioritization* for information about priority queue parameters.

- *Leaky bucket* -- Causes the router to actively police the unreserved traffic based on the unreserved bandwidth

  This method does not allow unreserved traffic to take advantage of available reserved bandwidth.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Unreserved Policing Algorithm** parameter. Site Manager: Unreserved Policing Algorithm parameter: page A-28	
4. Click on **OK**.	You return to the Configuration Manager window.

Specifying the Unreserved Queue Length

If the Unreserved Policing Algorithm parameter is set to Queue Limit, you can specify the maximum number of unreserved (best-effort) packets to be held in queue for transmission. After the queue length reaches this value, the router discards best-effort traffic when congestion occurs.

Note that priority queuing limits, if configured, override the value of this parameter.

By default, LRM holds a maximum of 20 unreserved packets in queue for transmission. Change this value to adjust the queue length limit from 0 to 214748364 packets (limited by available buffers).

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Unreserved Queue Length** parameter. Site Manager: Unreserved Queue Length parameter: page A-28	
4. Click on **OK**.	You return to the Configuration Manager window.

Specifying the Multiline Select Algorithm

If you configured LRM on a multiline circuit, you can choose one of two algorithms that determine how LRM selects which line to use for a new resource request:

- *First fit* -- Always uses the first available line that can service reserved traffic requests
- *Round robin* -- Rotates the use of lines available to service requests

All lines for a circuit must use the same algorithm. If any one line on a circuit specifies First Fit, all lines use the first fit algorithm.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Multiline Select Algorithm*** parameter. Site Manager: Multiline Select Algorithm parameter: page A-29	
4. Click on **OK**.	You return to the Configuration Manager window.

* You set this parameter only if you configured the Resource Manager on a multiline circuit.

Setting the Multiline Threshold Bandwidth

When using the first fit multiline select algorithm (see “Specifying the Multiline Select Algorithm” on page 8-12), you can configure a threshold of 0 to 214748364 b/s for the first available line.

By default, the threshold is set to 0; LRM uses the simple first fit algorithm. If you select a value greater than 0, LRM still uses the first available line with reservable bandwidth to service requests, but moves to the next available line after reaching the configured threshold. When all lines are at their threshold, LRM returns to using the simple first fit algorithm.

Set this parameter only if you have configured LRM on a multiline circuit and have set the Multiline Select Algorithm parameter to First Fit.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Multiline Threshold Bandwidth*** parameter. Site Manager: Multiline Threshold Bandwidth parameter: page A-29	
4. Click on **OK**.	You return to the Configuration Manager window.

* You set this parameter only if you configured the Resource Manager on a multiline circuit.

Setting the Reservation Latency

By default, the maximum latency for a reserved flow packet is 50 milliseconds (ms), limiting the amount of unreserved data that the link scheduler can transmit. When the data transmit ring reaches a size where the time to transmit the data is greater than the value of this parameter, no more unreserved data will be queued.

You can set the reservation latency from 0 to 214748364 ms. Reduce the value of this parameter to obtain better delay characteristics for reserved flows, but note that overall throughput may decrease. Increase the default value to improve throughput, but note that reserved-flow delays may increase.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Reservation Latency** parameter. Site Manager: Reservation Latency parameter: page A-30	
4. Click on **OK**.	You return to the Configuration Manager window.

Setting the Maximum Reservable Bandwidth for a Dataflow

By default, there is no maximum amount of bandwidth that can be reserved by a flow.

You can use the following Site Manager procedure to specify the maximum reservable bandwidth.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Largest Bandwidth** parameter. Site Manager: Largest Bandwidth parameter: page A-30	
4. Click on **OK**.	You return to the Configuration Manager window.

Setting the Maximum Buffer Space for a Dataflow

By default, there is no maximum on the amount of buffer space that can be used by a flow.

You can use the following Site Manager procedure to specify the maximum buffer space for a flow.

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, click on any connector for a line that is configured for RSVP.	The Edit Connector window opens.
2. Click on **Edit Line Resources** in the Edit Connector window.	The Edit Line Resources window opens.
3. Set the **Largest Buffer** parameter. Site Manager: Largest Buffer parameter: page A-30	
4. Click on **OK**.	You return to the Configuration Manager window.

Chapter 9
Configuring IGMP Relay

This chapter consists of the following topics:

Topic	Page
Concepts and Terminology	9-2
Enabling and Disabling IGMP Relay Globally	9-7
Specifying a Timeout Value for Multicast Table Entries	9-9
Configuring Upstream Data Forwarding	9-10
Specifying the Relay Interface Type	9-11
Configuring Unsolicited Reports on an Upstream Interface	9-13
Configuring an AS Boundary Router for Use with IGMP Relay	9-16
Configuring a Backup MOSPF Boundary Router	9-18
Configuring IGMP Relay with Router Redundancy	9-19

Concepts and Terminology

A router configured as an IGMP Relay (IGMP-R) device provides the following services for an MOSPF AS boundary router:

- Solicits multicast group membership information by sending IGMP host membership queries to hosts on its attached local networks
- Receives host membership reports and unsolicited join messages from hosts on attached networks and forwards them to the MOSPF boundary router
- Forwards multicast data to group members on locally attached networks

For more information about IGMP, see Chapter 3.

An IGMP-R device uses RIP to advertise its local networks. It does not run any multicast routing protocols (DVMRP or MOSPF).

An IGMP-R device is located physically between the IGMP hosts and the MOSPF boundary router. The hosts are considered to lie *downstream* of IGMP-R; the boundary router is *upstream*. The upstream link to the MOSPF router can be a frame relay link or a dial connection.

For redundancy, an IGMP-R device can be connected to two boundary routers, a *primary* router and a *backup* router. For example, Figure 9-1 shows an IGMP-R device with downstream interfaces to three networks containing IGMP hosts. The IGMP-R device also has an upstream interface to a primary boundary router and a second upstream interface to a backup boundary router on a dial-up line.



Figure 9-1. Multicast Network Topology with an IGMP Relay Device

To an IGMP host on a directly attached network, the IGMP-R device appears to be a multicast router. The host receives a host membership query from IGMP-R and responds by sending an IGMP response. A host can also send IGMP-R an unsolicited join message.

To the MOSPF AS boundary router, the IGMP-R device appears to be a locally attached host. The MOSPF router (which also runs IGMP) sends IGMP host queries to the IGMP-R. IGMP-R responds by forwarding -- relaying -- IGMP host reports and unsolicited join messages from its attached hosts.

In Figure 9-2, for example, the following events occur on the IGMP-R device:

1. IGMP-R sends IGMP host membership queries out the interfaces to LAN A, LAN B, and LAN C.
2. Host 1 on LAN A responds to the query by sending an IGMP host membership response to the IGMP-R device.
3. IGMP-R forwards the IGMP host membership response to the MOSPF boundary router.



Figure 9-2. IGMP-R Host Queries and Responses

In addition to soliciting multicast group membership information from directly attached networks, the IGMP-R device relays multicast data packets generated by downstream hosts to the upstream MOSPF boundary router or the appropriate upstream interface. IGMP-R also receives multicast data packets from the upstream router and forwards them to the appropriate group members.

In Figure 9-3, for example, the following events occur:

1. Host 1 generates a datagram addressed to a multicast group and sends it upstream to the IGMP-R device.
2. IGMP-R forwards the multicast datagram upstream to the MOSPF boundary router. IGMP-R also forwards the packet on a downstream interface to a local group member.
3. The MOSPF boundary router sends the datagram out the appropriate interface or interfaces to remote group members.



Figure 9-3. IGMP-R and Upstream Multicast Data

A downstream host can also send an unsolicited join message to the IGMP-R device. IGMP-R forwards the message upstream to the MOSPF boundary router.

In Figure 9-4, the following events occur:

1. A host on LAN B sends an unsolicited join message to IGMP-R. IGMP-R forwards the join message to the MOSPF boundary router.
2. The MOSPF boundary router receives a datagram addressed to the group that the host has joined.
3. The MOSPF boundary router forwards the datagram downstream to IGMP-R.
4. IGMP-R determines that a member of the group resides on LAN B and forwards the datagram on the downstream interface to LAN B.



Figure 9-4. IGMP-R and Downstream Multicast Data

Enabling and Disabling IGMP Relay Globally

By default, IGMP Relay is disabled on the router. You can use the BCC or Site Manager to enable and disable IGMP-R globally.

Using the BCC

Navigate to the global IGMP prompt and enter:

relay

The IGMP Relay prompt appears. IGMP Relay is now running and enabled globally.

For example:

```
igmp# relay
relay#
```

To disable IGMP Relay, navigate to the IGMP Relay prompt and enter:

delete

For example, the following command sequence invokes the IGMP Relay prompt, configures and enables IGMP Relay, and then disables IGMP Relay:

```
igmp# relay
relay# delete
relay#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **Relay** parameter to **Enable**. Site Manager: Relay parameter: page A-17	
6. Click on **Save**.	A dialogue box appears for the selection of a relay interface type.
7. Select a relay interface type as described in “Specifying the Relay Interface Type” on page 9-11.	You return to the Configuration Manager window.

When you configure the IGMP Relay function globally, Site Manager displays the IGMP Relay window. You use this window to specify the IGMP interface type for the interface you have selected. IGMP interfaces are described in “Specifying the Relay Interface Type” on page 9-11.

Specifying a Timeout Value for Multicast Table Entries

By default, the timeout period for an entry in the multicast table is 60 seconds if there is no multicast data to refresh the entry.

You can use the BCC or Site Manager to specify a value for this parameter.

Using the BCC

Navigate to the IGMP Relay prompt and enter:

fwd-lifetime *seconds*

seconds is the timeout period for an entry in the multicast table.

For example, the following command specifies a lifetime of 45 seconds for table entries:

```
relay# fwd-lifetime 45
relay#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **Relay Forwarding Lifetime** parameter. Site Manager: Relay Forwarding Timeout parameter: page A-18	
6. Click on **Save**.	You return to the Configuration Manager window.

Configuring Upstream Data Forwarding

By default, an IGMP-R device connected to a primary and backup MOSPF boundary router uses the primary upstream interface when both the primary and the backup interfaces are active. When only one interface is active, the IGMP-R device always uses that interface.

You can use the BCC or Site Manager to specify which interface to use for upstream data forwarding.

Using the BCC

Navigate to the IGMP Relay global prompt and enter:

fwd-option *option*

option is one of the options listed in Table 9-1.

Table 9-1. IGMP Relay Forwarding Options

Option	Meaning
Primary (default)	IGMP Relay uses the primary upstream interface only if both the primary interface and the backup interface are active.
Backup	IGMP Relay uses the backup upstream interface only if both the primary interface and the backup interface are active.
Both	IGMP Relay uses both the primary upstream interface and the backup upstream interface if both interfaces are active.

For example, the following command configures IGMP Relay to use both upstream interfaces if both interfaces are active:

```
relay# fwd-option both
relay#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Global**.	The IGMP Global Configuration window opens.
5. Set the **Relay Forwarding Options** parameter. Site Manager: Relay Upstream Forwarding parameter: page A-18	
6. Click on **Save**.	You return to the Configuration Manager window.

Specifying the Relay Interface Type

Use the Type parameter to specify that the IGMP-R interface is configured on one of the following types of interface:

- A downstream interface connecting the IGMP-R device to IGMP hosts (the default)
- An upstream interface connecting the IGMP-R device to the primary MOSPF boundary router
- An upstream interface connecting the IGMP-R device to the backup MOSPF boundary router

You can use the BCC or Site Manager to specify the interface type.

Using the BCC

Navigate to the interface-level IGMP prompt and enter:

relay

An interface-specific IGMP Relay prompt appears. Enter:

type *type*

type is one of the values listed in Table 9-2.

Table 9-2. IGMP Relay Interface Types

Interface Type	Meaning
downstream (default)	Downstream interface connecting IGMP Relay to IGMP hosts
upstream primary	Upstream interface connecting IGMP Relay to the primary MOSPF boundary router
upstream backup	Upstream interface connecting IGMP Relay to the backup MOSPF boundary router

For example, the following command sequence invokes an IGMP prompt for IP interface 2.2.2.2 and specifies that the interface is the upstream interface to the primary MOSPF boundary router:

```
igmp/2.2.2.2/1# relay
relay/2.2.2.2/1# type primary
relay/2.2.2.2/1#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Entry**.	The IGMP Entry Interface Parameters window opens.
5. Set the **Relay Circuit Type** parameter. Site Manager: Relay Circuit Type parameter: page A-22	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Configuring Unsolicited Reports on an Upstream Interface

By default, an IGMP-R device sends an unsolicited group report on the upstream interface. After an interval of 10 seconds, IGMP sends a second report.

Using the BCC or Site Manager, you can specify the interval between the first and second unsolicited report or configure IGMP Relay to send one unsolicited report only.

Using the BCC

Navigate to an interface-level IGMP prompt and enter:

relay

Navigate to an interface-specific IGMP Relay prompt and enter:

report-interval *interval*

interval is one of values described in Table 9-3.

Table 9-3. Unsolicited IGMP Report Interval

Value	Meaning
0	Configures IGMP Relay to send only one unsolicited group report on this interface
1-255 (Default is 10)	Configures how long IGMP Relay waits to repeat the unsolicited report

For example, the following command configures IGMP Relay to repeat the unsolicited report after 30 seconds:

```
relay/2.2.2.2/1# report-interval 30
relay/2.2.2.2/1#
```

Using Site Manager

Site Manager Procedure	
You do this	**System responds**
1. In the Configuration Manager window, choose **Protocols**.	The Protocols menu opens.
2. Choose **IP**.	The IP menu opens.
3. Choose **IGMP**.	The IGMP menu opens.
4. Choose **Entry**.	The IGMP Entry Interface Parameters window opens.
5. Set the **Relay Report Interval** parameter. Site Manager: Relay Report Interval parameter: page A-22	
6. Click on **Apply**, and then click on **Done**.	You return to the Configuration Manager window.

Configuring an AS Boundary Router for Use with IGMP Relay

An IGMP-R device communicates with a router configured as an MOSPF AS boundary router. To configure a router for use with an IGMP-R device, you must do the following:

- Configure the router as an MOSPF AS boundary router. For information on OSPSF, see *Configuring IP Services*. For information on MOSPF, see Chapter 5.
- Set the MOSPF Multicast Downstream IGMP Relay parameter to Enabled. For information, see “Configuring Multicast-Capable External Routes” on page 5-11.
- Configure RIP globally on the MOSPF boundary router. For information about RIP, see *Configuring IP Services*.
- Add MOSPF and IGMP to each interface that connects the router to the multicasting domain.
- Add RIP, MOSPF, and IGMP to the downstream interface that connects the router to the IGMP-R device. Note that MOSPF is configured on the multicast interface only. As a unicast device, IGMP-R does not run MOSPF or any other multicast protocol on the upstream interface to the MOSPF boundary router.
- Add RIP to the downstream interface that connects the MOSPF boundary router with the IGMP-R device.



Figure 9-5. IGMP-R Routing Protocols

Figure 9-5 shows how a Bay Networks MOSPF AS boundary router receives RIP and IGMP advertisements from IGMP-R and injects them into the OSPF domain. The following events occur:

1. The MOSPF boundary router receives a RIP advertisement from IGMP-R and injects it into the MOSPF domain as an AS external route.
2. The MOSPF boundary router receives IGMP host membership responses from IGMP-R and floods group membership LSAs to other MOSPF routers in the domain.

Configuring a Backup MOSPF Boundary Router

IGMP Relay supports two types of backup configuration:

- Configurations that contain a primary and a backup MOSPF boundary router
- Configurations that contain a primary and a backup IGMP-R

In Figure 9-6, for example, an IGMP Relay device has interfaces to two MOSPF boundary routers. A leased line connects the IGMP-R to the primary MOSPF boundary router. A dial-up line connects the IGMP-R to the backup MOSPF boundary router.



Figure 9-6. IGMP Relay with Primary and Backup Boundary Routers

For information on configuring a dial connection, see *Configuring Dial Services*.

Configuring IGMP Relay with Router Redundancy

IGMP operates with BayRS router redundancy in hot stand-by mode.

Figure 9-7 shows a topology with two IGMP Relay devices configured for router redundancy. One of the IGMP Relay devices is configured as the primary device; the other is configured as the secondary device. When the primary device is active, it is responsible for all IGMP Relay functions as well as all routing features associated with the device. The secondary device remains in a passive mode with the protocols loaded but not actively processing or sending information.

If the secondary device determines that the primary device is inactive, the secondary device transitions to the active state, assuming all functions, including the IGMP Relay function. The original primary device transitions to the secondary state.



Figure 9-7. IGMP Relay with Router Redundancy

For information, see *Configuring Router Redundancy.*

Appendix A
Site Manager Parameters

For each parameter associated with a multicast protocol or service, this appendix provides the Site Manager menu path to each parameter, information about default settings, valid parameter options, the parameter function, instructions for setting the parameter, and the MIB object ID. Find parameters under the following topics:

Topic	Page
DVMRP Parameters	page A-2
IGMP Parameters	page A-15
IP Configuration Parameters	page A-23
Resource Manager Parameters	page A-25
OSPF Parameters for Multicast and QoS Extensions	page A-31
RSVP Parameters	page A-35

DVMRP Parameters

This section describes the DVMRP global, circuit, and tunnel parameters.

DVMRP Global Parameters

Parameter: **Enable**
Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global
Default: Enable
Options: Enable | Disable
Function: Enables and disables DVMRP support on the router.
Instructions: To disable DVMRP once you have configured it on the router, specify Disable.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.2

Parameter: **Full Update Interval**
Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global
Default: 60
Options: 10 to 2000 seconds
Function: Specifies how often routing messages containing complete routing tables are sent.
Instructions: Determine the full update interval you require and specify a value.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.4

Parameter: **Triggered Update Interval**
Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global
Default: 5
Options: 5 or more seconds
Function: Specifies the minimum amount of time between triggered updates.
Instructions: Triggered updates are sent in the period between full updates. Issuing a full update restarts the triggered update timer. Therefore, the triggered update interval you specify must be shorter than the full update interval you specified with the Full Update Interval parameter.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.5

Parameter: Leaf Timeout

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global
Default: 200
Options: 25 to 4000 seconds
Function: Specifies a value for the Leaf Timeout timer.
Instructions: Determine the timer interval you require and specify a value.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.6

Parameter: Neighbor Timeout

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global
Default: 140
Options: 40 to 8000 seconds
Function: Specifies how long a connection with a router neighbor is considered active without receiving a subsequent probe or report from the neighbor.
Instructions: Determine a neighbor timeout period and specify a value.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.7

Parameter: Route Expiration Timeout

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global
Default: 200
Options: 20 to 4000 seconds
Function: Specifies how long a route is considered valid without the receipt of a subsequent update indicating that the route is reachable. This value represents the duration of time that this route will be used. Upon expiration of this timer, this route is advertised as unreachable until it is refreshed or deleted.
Instructions: Enter a value that represents the duration of time this route will be used without being refreshed.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.8

Parameter: **Garbage Timeout**

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global

Default: 340

Options: 40 to 8000 seconds

Function: Specifies the duration of time that this route will be included in routing updates without the receipt of a subsequent update indicating that the route is reachable. The difference between this value and the Route Expiration Timeout value represents the duration of time that the route will be advertised as unreachable without subsequent refreshment.

Instructions: Enter a value that is greater than the value you specified for Route Expiration Timeout to allow for sufficient time for the route to be advertised as unreachable.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.9

Parameter: **Estimated Routes**

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global

Default: 25

Options: An integer of 10 or greater

Function: Specifies the estimated number of routes.

Instructions: Enter a value that the router can use for preallocating routing tables. For an MBone implementation, a value of 3000 or higher is recommended. Note that routes are kept on a per-source-network basis, independent of multicast groups. This number must include a route for every network that is local to a circuit configured for multicasting. This allows the router to utilize memory efficiently. Exceeding this size during router operation will not cause an error but may cause the router to consume more memory than is required.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.10

Parameter: Neighbor Probe Interval

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global

Default: 10

Options: 5 to 30 seconds

Function: Specifies how often DVMRP should send a probe on interfaces from which no neighbors have been heard.

Instructions: If your neighbor is running DVMRP *mrouted*, ensure that your probe interval value matches the value used by the neighbor.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.11

Parameter: Route Switch Timeout

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global

Default: 140

Options: 20 to 2000 seconds

Function: Specifies how long DVMRP should wait, without receiving a subsequent route update from the original neighbor, before switching to a different neighbor advertising equal cost for this route.

Instructions: If your neighbor is running DVMRP *mrouted*, the recommended value is 140 seconds.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.12

Parameter: Debug Level

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global

Default: 0

Options: 0 or a debug level

Function: Turns the DVMRP log on or off for DVMRP debugging messages and specifies the level of debug messages.

Instructions: By default (0), the log is turned off. Specify a level only when directed by Customer Support personnel to investigate a problem.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.14

Parameter: Pruning Enable

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global
Default: Enable
Options: Enable │ Disable
Function: Enables or disables pruning functionality on the router.
Instructions: DVMRP performs route pruning by default. If you want to disable this function on the router, select Disable.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.15

Parameter: Max Routes

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global
Default: 0
Options: 0 or an integer
Function: Specifies the number of routes that DVMRP can learn per slot. This parameter limits the number of routes that can be stored in the routing table.
Instructions: If you want DVMRP to store all learned routes in the routing table, use the default, 0. If you specify a maximum number of routes, you must include a route for every local network that has a circuit configured for multicasting.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.17

Parameter: Policy Enable

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Global
Default: Disable
Options: Enable │ Disable
Function: Enables and disables route policy functionality at the global level.
Instructions: Set this parameter as required.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.1.18

DVMRP Circuit Parameters

Parameter: Enable

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit
Default: Enable
Options: Enable | Disable
Function: Enables or disables DVMRP on this circuit.
Instructions: If you have configured DVMRP on this circuit, enter Disable to disable it.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.2.1.2

Parameter: Route Enable

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit
Default: Enable
Options: Enable | Disable
Function: Enables or disables this circuit for routing.
Instructions: Specify Enable if you want this circuit to be used to propagate routing information, and if you want information about the source network associated with this circuit incorporated into routing updates. Specify Enable if you want multicast datagrams to be forwarded on this circuit in “native mode” -- that is, as multicast datagrams. You can configure tunnels on this circuit.

Specify Disable if you want this circuit to exist only to support unicast tunnels. If you specify Disable, all other DVMRP circuit parameters are ignored. The source network associated with this circuit is not incorporated into the routing updates.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.2.1.5

Parameter: Metric

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit

Default: 1

Options: 1 to 31

Function: Specifies the cost of this interface.

Instructions: Determine the cost that you want to assign to this hop and enter a value. We recommend the following values: for a LAN, or tunnel across a single LAN, 1; for a multihop tunnel, 2 or 3; for a serial link, or tunnel across a serial link, 1; for a backup tunnel, the primary tunnel metric + 1.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.2.1.6

Parameter: Threshold

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit

Default: 1

Options: 1 to 254 hops

Function: Specifies a TTL value for the interface. This value is the minimum IP TTL required for a multicast datagram to be forwarded out this interface.

Instructions: Use this parameter to control the scope of the datagrams. If the IP TTL is less than the threshold value you specify, the router drops the datagram.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.2.1.7

Parameter: Forward Cache Size

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit

Default: 32

Options: 32 to 512 entries

Function: Specifies the maximum number of entries allowed in the forwarding table associated with this interface.

Instructions: When configuring a cache size, you must also keep in mind the TTL value for entries. If you specify a large cache size, a larger TTL value is recommended. For a smaller cache, a shorter TTL for cache entries is recommended.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.2.1.14

Parameter: **Forward Cache TTL**

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit

Default: 700

Options: 300 to 86400 seconds

Function: Specifies the TTL for an entry in the forwarding table.

Instructions: If your neighbor is running DVMRP *mrouted*, Bay Networks recommends a TTL value of 300 seconds.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.2.1.15

Parameter: **Advertise Self**

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit

Default: Advertise

Options: Advertise | Do Not Advertise

Function: Specifies whether the router advertises its own local networks over this interface.

Instructions: If you do not want routes advertised over a particular interface, set that interface to Do Not Advertise.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.2.1.16

Parameter: **Route Supply**

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit

Default: Disable

Options: Enable | Disable

Function: Supplies the default route (0.0.0.0) on this interface.

Instructions: Enable this feature if you want DVMRP to advertise a default route on this interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.2.1.24

Parameter:	**Route Listen**
Path:	Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit
Default:	Disable
Options:	Enable | Disable
Function:	Receives the default route (0.0.0.0) on this interface.
Instructions:	Enable this feature if you want DVMRP to listen for a default route on this interface.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.12.2.1.25

Parameter:	**Report Depend Probe**
Path:	Configuration Manager > Protocols > IP > Multicast > DVMRP > Circuit
Default:	Disable
Options:	Enable | Disable
Function:	Specifies the conditions under which DVMRP accepts a route report. According to the protocol, DVMRP must send a probe packet before sending the route report packet to its neighbors. Some vendor implementations, however, do not send probes before sending reports.
Instructions:	By default, DVMRP processes all received route reports. Enable this feature if you want DVMRP to process only routes received from neighbors that send probe packets.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.12.2.1.26

DVMRP Tunnel Parameters

Parameter: Enable

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel
Default: Enable
Options: Enable | Disable
Function: Enables or disables this tunnel interface.
Instructions: If you have configured this tunnel, specify Disable to disable the tunnel.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.3.1.2

Parameter: Encapsulation Mode

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel
Default: IP Datagram
Options: IP Datagram | LSSR Option
Function: Specifies whether tunneled datagrams are encapsulated within an IP datagram or loosely encapsulated using the LSSR option.
Instructions: See RFC 1075 for information about the LSSR option, which is provided for backward compatibility.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.3.1.6

Parameter: Metric

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel
Default: 1
Options: 1 to 31
Function: Specifies the cost of this tunnel.
Instructions: Determine the cost you want to assign to this tunnel and enter a value.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.3.1.7

Parameter: Threshold

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel
Default: 1
Options: 1 to 254 hops
Function: Specifies a TTL value for the tunnel. This value is the minimum IP TTL required for a multicast datagram to be forwarded out this tunnel.
Instructions: Use this parameter to control the scope of the datagrams. If the IP TTL is less than the threshold value you specify, the router drops the datagram.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.3.1.8

Parameter: Forward Cache Size

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel
Default: 32
Options: 32 to 512 entries
Function: Specifies the maximum number of entries allowed in the forwarding table associated with this tunnel interface.
Instructions: When configuring a cache size, you must also keep in mind the TTL value for entries. If you specify a large cache size, a larger TTL value is recommended. For a smaller cache, a shorter TTL for cache entries is recommended.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.3.1.16

Parameter: Forward Cache TTL

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel
Default: 300
Options: 300 to 86400 seconds
Function: Specifies the TTL for an entry in the forwarding table.
Instructions: Select an appropriate value for your configuration.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.3.1.17

Parameter: **Route Supply**

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel

Default: Disable

Options: Enable │ Disable

Function: Supplies the default route (0.0.0.0) on this interface.

Instructions: Enable this feature if you want DVMRP to advertise a default route on this interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.3.1.25

Parameter: **Route Listen**

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel

Default: Disable

Options: Enable │ Disable

Function: Receives the default route (0.0.0.0) on this interface.

Instructions: Enable this feature if you want DVMRP to listen for a default route on this interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.3.1.26

Parameter: **Control Message Mode**

Path: Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel

Default: Noencaps

Options: Encaps │ Noencaps

Function: Specifies the encapsulation mode for IGMP control packets.

Noencaps causes IGMP to send control messages in regular IGMP packets with the IP protocol type set to IP_PROTOCOL_IGMP.

Encaps causes IGMP to encapsulate control messages inside IP packets with the IP protocol type set to IP_PROTOCOL_IPINIP.

All DVMRP messages sent across tunnels will be encapsulated in the same way as data packets in this mode.

Instructions: Select an encapsulation mode for control messages.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.12.3.1.27

Parameter:	**Report Depend Probe**
Path:	Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel
Default:	Disable
Options:	Enable | Disable
Function:	Specifies the conditions under which DVMRP accepts a route report. According to the protocol, DVMRP must send a probe packet before sending the route report packet to its neighbors. Some vendor implementations, however, do not send probes before sending reports.
Instructions:	By default, DVMRP processes all received route reports. Enable this feature if you want DVMRP to process only routes received from neighbors that have sent probe packets in accordance with the protocol.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.12.3.1.28

Parameter:	**Local IP Address**
Path:	Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel > Click on **Add**
Default:	Null
Options:	The unicast IP address of an interface on a circuit supporting multicasting on the local router
Function:	Identifies the local end of the tunnel. To identify a unicast tunnel, you must supply the unicast IP address of both ends of the tunnel: the local interface and the remote interface.
Instructions:	Use this parameter to enter the local IP address.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.12.3.1.4

Parameter:	**Remote IP Address**
Path:	Configuration Manager > Protocols > IP > Multicast > DVMRP > Tunnel > Click on **Add**
Default:	Null
Options:	The unicast IP address of an interface supporting multicasting on a neighboring router
Function:	Identifies the remote end of the tunnel. To identify a unicast tunnel, you must supply the unicast IP address of both ends of the tunnel: the local interface and the remote interface.
Instructions:	Use this parameter to enter the remote IP address.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.12.3.1.5

IGMP Parameters

This section describes the IGMP global configuration, static host, and entry interface parameters.

IGMP Global Configuration Parameters

Parameter:	**Enable**
Path:	Configuration Manager > Protocols > IP > Multicast > IGMP > Global
Default:	Enable
Options:	Enable | Disable
Function:	Enables or disables this IGMP record.
Instructions:	If you configured IGMP on this router, use this parameter to disable it.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.13.1.2

Parameter: Estimated Groups

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global

Default: 20

Options: 5 to 65535 groups

Function: Specifies the estimated number of groups that will be simultaneously active for this router.

Instructions: Determine the approximate number of groups and enter the value. This allows the router to utilize memory efficiently. Exceeding this size during router operation will not cause an error but may cause the router to consume more memory than required. The following groups are not maintained by IGMP; you do not need to include them in the count: 224.0.0.1, 224.0.0.4, 224.0.0.5, and 224.0.0.6.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.1.4

Parameter: Version Threshold Time

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global

Default: 540

Options: 1 to 65535 seconds

Function: The number of seconds that can elapse after IGMP detects a Version 1 query before IGMP tries to become the designated querier.

Instructions: The value you specify should be greater than the Version 1 query rate of all IGMP speakers on all networks directly connected to the router.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.1.5

Parameter: Join Ack Enable

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global

Default: Disable

Options: Enable │ Disable

Function: Indicates whether IGMP should send an immediate response (in the form of a query) to the group associated with this IGMP membership report.

Instructions: Set this parameter as required.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.1.7

Parameter: **Forward Cache Limit**

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global

Default: 512

Options: 64 to 65535

Function: Specifies the maximum number of MTM forwarding cache errors.

Instructions: Set this parameter as required.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.1.8

Parameter: **Debug**

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global

Default: None

Options: See instructions.

Function: Causes IGMP to generate log messages.

Instructions: Set the following bits in any combination to specify the log messages you want IGMP to generate:

0x00000001 for received IGMP join/leave packets
0x00000002 for sent IGMP messages
0x00000004 for received multicast protocol messages
0x00000008 for MTRACE log messages
0x00000010 for configuration log messages
0x00000020 for interaction with multicast protocols
0x00000040 for interaction with RSVP
0x00000080 for MTM forwarding cache log messages
0x00000100 for IGMP-R log messages

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.1.6

Parameter: **Relay**

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global

Default: Disable

Options: Enable │ Disable

Function: Enables and disables IGMP-R.

Instructions: Set the parameter as required.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.1.10

Parameter: **Nonlocal Reports**

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global

Default: Ignore

Options: Ignore │ Accept

Function: Controls whether IGMP accepts or ignores leave and join messages from a nonlocal network.

Instructions: Set the parameter as required by your configuration.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.1.9

Parameter: **Relay Forwarding Timeout**

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global

Default: 60 seconds

Options: Any integer

Function: Sets the timer with the number of seconds for aging out IGMP-R MTM forwarding entries.

Instructions: Set the timer as required by your configuration.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.1.11

Parameter: **Relay Upstream Forwarding**

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global

Default: Primary

Options: Primary │ Backup │ Both

Function: Specifies whether multicast data is forwarded from the IGMP-R onto the primary upstream interface, the backup interface, or both when both interfaces are active.

Instructions: Select an option as required by your configuration.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.1.12

IGMP Static Host Parameters

Parameter: Circuit Name

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global
Default: None
Options: A circuit number
Function: Specifies the circuit number for the local network on which the group member resides.
Instructions: Use the Static Group parameters to manually register the network on which the multicast group member resides.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.4.1.2

Parameter: Static Group Address

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global
Default: None
Options: A multicast address
Function: Specifies the multicast address for the group of which the host is a member.
Instructions: Use the Static Group parameters to manually register the network on which the multicast group member resides.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.4.1.3

Parameter: Prefix Length

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Global
Default: None
Options: The length of the address prefix
Function: Specifies the length of the prefix of the multicast group address.
Instructions: Use the Static Group parameters to manually register the network on which the multicast group member resides.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.4.1.4

IGMP Entry Interface Parameters

Parameter: Enable

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Entry
Default: Enable
Options: Enable │ Disable
Function: Indicates whether this IGMP interface record is enabled or disabled.
Instructions: If you configured IGMP on this interface, use this parameter to disable it.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.2.1.2

Parameter: Interface Query Rate

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Entry
Default: 120
Options: 0 to 4096 seconds
Function: Specifies how often the router sends group membership queries on the interface.
Instructions: If there are no multicast hosts on this circuit, set the parameter to 0 to disable queries. Specifying 0 affects queries only. The router still forwards multicast datagrams on this circuit. If another IGMP router on this network has taken on the query role, this router will not send queries unless it has not heard of any queries within the number of seconds specified by the Designated Router Timeout parameter.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.2.1.5

Parameter: Interface Membership Timeout

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Entry
Default: 260
Options: 30 to 8192 seconds
Function: Specifies the amount of time that a local group membership is valid without the receipt of a subsequent report for that group.
Instructions: The suggested value is (2 * Query Rate) + 20.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.2.1.6

Parameter: Designated Router Timeout

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Entry

Default: 140

Options: 10 to 8192 seconds

Function: Specifies the amount of time that can elapse after the last host query message before the IGMP designated router is considered down.

Instructions: The value you specify should be greater than the query rate of all IGMP routers on the network.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.2.1.7

Parameter: Max Host Response Time

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Entry

Default: 100

Options: 1 to 100 tenths of a second

Function: Specifies a maximum value for the amount of time that a host must wait before responding to a query. IGMP places this value in the code field of an IGMP query.

Instructions: Specify a maximum response time for this interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.2.1.15

Parameter: Mtrace Entry Lifetime

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Entry

Default: 30 seconds

Options: 30 to 8192 seconds

Function: Specifies the amount of time that a router should keep a forwarding cache entry that was created specifically for Mtrace.

Instructions: Specify an Mtrace lifetime value for the interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.2.1.18

Parameter: Query Suppression

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Entry

Default: No

Options: Yes │ No

Function: Specifies whether IGMP queries are suppressed on this interface.

Instructions: In the Bay Networks multicast implementation, configuring IGMP on an interface means two things: (1) the interface is used for forwarding multicast traffic and (2) the IGMP protocol is running on the interface. Therefore, on some interfaces -- for example, point-to-point or nonbroadcast -- even though there is no need to run the IGMP protocol, IGMP must still be configured. On such interfaces, you can disable the sending of IGMP queries.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.2.1.25

Parameter: Relay Circuit Type

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Entry

Default: Downstream

Options: Primary │ Backup │ Downstream

Function: Specifies whether the IGMP circuit is configured as the primary upstream circuit, the backup upstream circuit, or a downstream (norelay) circuit.

Instructions: You can configure only one primary and one backup circuit on the router.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.2.1.23

Parameter: Relay Report Interval

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Entry

Default: 10

Options: 0 to any integer

Function: Specifies the interval (in seconds) between the initial group membership report on an IGMP-R primary or backup circuit and a repetition of that report.

Instructions: Using 0 causes IGMP-R to send an unsolicited group report once only.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.2.1.24

IP Configuration Parameters

Parameter: IP Address

Path: Select IP from the Select Protocols window and click on OK.

Default: None

Options: 0.0.0.0 or any valid IP address

Function: Assigns a 32-bit IP address to the interface.

Instructions: Enter the IP address of the interface in dotted-decimal notation. Enter 0.0.0.0 to configure an unnumbered interface on the circuit.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.1.4.1.4

Parameter: Subnet Mask

Path: Select IP from the Select Protocols window and click on OK.

Default: None

Options: The Configuration Manager automatically calculates an appropriate subnet mask, depending on the class of the network to which the interface connects. However, you can change the subnet mask with this parameter.

Function: Specifies the network and subnetwork portion of the 32-bit IP address.

Instructions: Either accept the assigned subnet mask or enter another subnet mask in dotted-decimal notation. Enter 0.0.0.0 if you are configuring an unnumbered interface on the circuit.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.1.4.1.6

Parameter: Transmit Bcast Addr

Path: Select IP from the Select Protocols window and click on OK.

Default: 0.0.0.0

Options: 0.0.0.0 or any valid IP broadcast address

Function: Specifies the broadcast address that this IP subnet uses to broadcast packets. Accepting 0.0.0.0 for this parameter specifies that the IP router will use a broadcast address with a host portion of all 1s. Accepting 0.0.0.0 does not configure the router to use the address 0.0.0.0 to broadcast packets. For example, if you have IP address 123.1.1.1 and a subnet mask of 255.255.255.0, accepting the default value 0.0.0.0 configures the IP router to use the address 123.1.1.255 to broadcast packets. To set the explicit broadcast address of all 1s, enter 255.255.255.255 for this parameter.

Instructions: Accept the default, 0.0.0.0, unless the calculated broadcast address (host portion) of all 1s is not adequate. If this is the case, then enter the appropriate IP broadcast address in dotted-decimal notation. If you set the IP Address parameter to 0.0.0.0 (to configure an unnumbered interface), Site Manager automatically sets this parameter to 255.255.255.255.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.1.4.1.8

Parameter: UnNumbered Assoc Address

Path: Select IP from the Select Protocols window and click on OK.

Default: None

Options: Any valid IP address

Function: Specifies an address that IP uses when sourcing a packet. RIP uses this address to make decisions about advertising subnets over the unnumbered interface. RIP advertises subnets over the unnumbered interface if the subnets have the same mask as the associated address.

Instructions: Specify the address of any numbered interface on the router. If you are running RIP over the unnumbered interface and if you are using a subnet address as the associated address, the local and remote associated addresses should have the same network number. If you configure local and remote associated addresses using different network numbers, you must use RIP2 mode.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.1.4.1.110

Resource Manager Parameters

Parameter: Estimated Bandwidth

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: 0

Options: 0 to 214748364 b/s

Function: Specifies the estimated usable bandwidth for this line.

Instructions: Enter the estimated total bandwidth for this line in bits per second. To enable line resource management, enter a value greater than zero. For point-to-point lines, you can usually enter the total line speed.

For an Ethernet line, you must estimate a value, because shared-media lines may not have all of the bandwidth available. You can base the estimate on line statistics, the number of connected workstations, or other site-specific information.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.3

Parameter: Reservable Bandwidth

Path: XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: 0

Options: 0 to 214748364 b/s

Function: Specifies the reservable bandwidth for this line.

Instructions: To enable reservable resources, enter the portion of this line's bandwidth that you want to make available for RSVP requests for guaranteed service. The value must be greater than 0 and less than the value of the Estimated Bandwidth parameter. Do not make all available bandwidth reservable; leave at least 15 percent for network management and routing protocols.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.4

Parameter: Traffic Queuing Algorithm

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: None

Options: None | Priority

Function: Specifies the queuing algorithm for all reserved traffic.

Instructions: Select None to use best-effort scheduling. Use best-effort scheduling if you want to use the resource reservation protocol (RSVP) to control admission of flows to the network, but do not want to explicitly schedule each flow's packets.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.5

Parameter: Policing Algorithm

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: None

Options: None | Leaky Bucket

Function: Specifies whether or not to use the leaky bucket policing algorithm for reserved traffic. With leaky bucket policing, the Resource Manager makes sure that all RSVP packets using reserved bandwidth follow the flowspec that appears in the RSVPRSVP connect request. The Resource Manager discards any packets that do not adhere to the flowspec. Note that such policing requires additional processing by the router.

Instructions: Select None to bypass policing if an upstream router is policing traffic, or if the applications generating the reserved traffic consistently adhere to the flowspec and do not require policing.

Enter Leaky Bucket to apply a leaky bucket policing algorithm to reserved traffic.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.6

Parameter: Bandwidth Interval (Secs)

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: 10

Options: 1 to 214748364 seconds

Function: Specifies the interval over which the Resource Manager measures instantaneous bandwidth.

Instructions: Enter a time interval in seconds if the default value of 10 seconds is not sufficient.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.7

Parameter: Inflate Reservations Percentage

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: 0

Options: 0 to 100 percent

Function: Specifies that the Resource Manager adds a safety buffer to each RSVP reservation on this line by increasing bandwidth requests by a specified percentage.

Instructions: To inflate reservations made on this line, enter a percent value to increase each bandwidth request. Increase the value of this parameter if you notice that the Resource Manager is discarding packets because applications generating reserved traffic are exceeding their flowspecs.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.8

Parameter: Unreserved Policing Algorithm

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: Queue Limit

Options: Queue Limit | Leaky Bucket

Function: Specifies the policing algorithm for unreserved traffic.

Instructions: Select the Queue Limit option to restrict the number of buffers (packets) of unreserved traffic that the Resource Manager queues. This method of policing enables unreserved traffic to use available reserved bandwidth. The Unreserved Queue Length parameter specifies the maximum number of packets in the queue.

Select the Leaky Bucket option to cause the router to actively police the unreserved traffic based on the unreserved bandwidth. This method does not allow unreserved traffic to take advantage of available reserved bandwidth.

If you enable priority queuing for this line, the router uses the priority queue parameters to perform Queue Limit policing. See *Configuring Traffic Filters and Protocol Prioritization* for information about priority queue parameters.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.9

Parameter: Unreserved Queue Length

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: 20

Options: 0 to 214748364 packets (limited by available buffers)

Function: If the Unreserved Policing Algorithm parameter is set to Queue Limit, this parameter specifies the maximum number of unreserved (best-effort) packets to be held in queue for transmission.

After the queue length reaches this value, the router discards best-effort traffic when congestion occurs.

Priority queuing limits, if configured, override the value of this parameter.

Instructions: Change this value to adjust the queue length limit.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.10

Parameter: **Multiline Select Algorithm**

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: First Fit

Options: First Fit | Round Robin

Function: Specifies how the Resource Manager selects which line to use for a new resource request, if you have the Resource Manager configured on a multiline circuit.

Instructions: Set this parameter only if you configured the Resource Manager on a multiline circuit.

Select First Fit to always use the first available line that can service reserved traffic requests. Select Round Robin to rotate the use of lines available to service requests. All lines for a circuit must use the same algorithm. If any one line on a circuit specifies First Fit, all lines use the first fit algorithm.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.11

Parameter: **Multiline Threshold Bandwidth**

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: 0

Options: 0 to 214748364 b/s

Function: Specifies how the first fit algorithm works, providing you set the Multiline Select Algorithm parameter to First Fit. If you accept the default value, the Resource Manager uses the simple first fit algorithm. If you select a value greater than 0, the Resource Manager still uses the first available line with reservable bandwidth to service requests, but moves to the next available line after reaching the configured threshold. When all lines are at their thresholds, the Resource Manager resumes using the simple first fit algorithm.

Instructions: Set this parameter only if you have configured the Resource Manager on a multiline circuit and have set the Multiline Select Algorithm parameter to First Fit.

Accept the default or enter a number less than the value of the Reservable Bandwidth parameter.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.12

Parameter: Reservation Latency

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: 50

Options: 0 to 214748364 milliseconds

Function: Specifies the maximum latency for a reserved flow packet, limiting the amount of unreserved data that the link scheduler can transmit. When the data transmit ring reaches a size where the time to transmit the data is greater than the value of this parameter, no more unreserved data will be queued.

Instructions: Reduce the value of this parameter to obtain better delay characteristics for reserved flows, but note that overall throughput may decrease. Increase the default value to improve throughput, but note that reserved-flow delays may increase.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.13

Parameter: Largest Bandwidth

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: 0 (no maximum)

Options: 0 or an integer indicating the percentage of bandwidth

Function: Specifies the maximum bandwidth that a single flow can reserve on this line.

Instructions: Set this parameter as required.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.14

Parameter: Largest Buffer

Path: Configuration Manager > XCVR, HSSI, MCT1, or COM Connector configured for the RSVP protocol > Edit Line Resources > Edit Line Resources

Default: 0 (no maximum)

Options: 0 or an integer specifying the amount of buffer space

Function: Indicates the maximum buffer space that a single flow can reserve on this line.

Instructions: Set this parameter as required.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.2.1.3.1.15

OSPF Parameters for Multicast and QoS Extensions

OSPF Global Parameters

Parameter: Multicast Extensions

Path: Configuration Manager > Protocols > IP > OSPF > Global
Default: 0
Options: 0 (no multicast forwarding is enabled) | 1 (intra-area multicasting only) | 3 (intra-area and inter-area multicasting) | 5 (intra-area and inter-AS multicasting) | 7 (multicasting everywhere)
Function: Enables OSPF multicast extensions and specifies the type of multicasting.
Instructions: Set the parameter as required.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.3.1.19

Parameter: Multicast Deterministic

Path: Configuration Manager > Protocols > IP > OSPF > Global
Default: Nondeterministic
Options: Nondeterministic | Deterministicstrict | Deterministicloose
Function: Selects the MOSPF mode.
Instructions: Select the appropriate variation of the Dykstra algorithm.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.3.1.20

Parameter: Multicast Route Pinning

Path: Configuration Manager > Protocols > IP > OSPF > Global
Default: Nonpinned
Options: Nonpinned | Pinned
Function: Selects pinned or nonpinned mode.
Instructions: Select the appropriate variation of the Dykstra algorithm.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.3.1.21

Parameter: **Opaque Capability**

Path: Configuration Manager > Protocols > IP > OSPF > Global

Default: Enabled

Options: Enabled │ Disabled

Function: Controls whether or not OSPF accepts and processes opaque LSAs.

Instructions: Select Disable if you do not want OSPF to accept opaque LSAs.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.3.1.22

Parameter: **Deterministic Mcast Hold Down**

Path: Configuration Manager > Protocols > IP > OSPF > Global

Default: Disabled

Options: Enabled │ Disabled

Function: Controls whether or not the Hold Down feature for deterministic MOSPF is enabled.

Instructions: Enable this feature if you want a data flow to go out an interface only if there is a reservation for the flow on the interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.3.1.25

Parameter: **Timeout Value**

Path: Configuration Manager > Protocols > IP > OSPF > Global

Default: 600 seconds

Options: An integer

Function: Specifies a timer value for timing out MOSPF forward entries.

Instructions: Use the default setting.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.3.1.26

Parameter: **Max Queued Multcast Packets**

Path: Configuration Manager > Protocols > IP > OSPF > Global

Default: 64

Options: An integer indicating the number of packets

Function: Controls how many multicast packets OSPF can queue on each slot before it finishes calculating multicast trees.

Instructions: If you specify 0, OSPF drops packets before the tree is calculated.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.3.1.27

Parameter: **Dynamic TTL**

Path: Configuration Manager > Protocols > IP > OSPF > Global

Default: Disabled

Options: Enabled │ Disabled

Function: Controls whether MOSPF uses a dynamic TTL threshold. Dynamic TTL means that the TTL threshold may be different for each (source, group, downstream) tuple.

Instructions: For maximum forwarding performance, disable this feature.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.3.1.28

Parameter:	**Multicast Downstream IGMP Relay**
Path:	Configuration Manager > Protocols > IP > OSPF > Global
Default:	Disabled
Options:	Enabled │ Disabled
Function:	Specifies whether AS external routes are multicast capable. If you enable this feature, the advertising ASBR sets the multicast bit in the ASE-LSAs for those routes, so that they can be used for multicast purposes.
Instructions:	By default, all external routes are multicast capable. However, if you know that an ASBR's external routes can be used for unicast only, you must set this parameter to Disabled on the ASBR. For example, consider two ASBRs -- ASBR1 and ASBR2 -- each with a BGP connection to an ISP. You know that all multicast traffic should be injected into the MOSPSF domain by ASBR2 because ASBR2 has a DVMRP tunnel to the Mbone. To prevent ASBR1 from injecting multicast routes into the MOSPF domain, you set this parameter to Disabled.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.2.3.1.30

OSPF Interface Parameters

Parameter:	**Multicast Forwarding**
Path:	Configuration Manager > Protocols > IP > OSPF > Interfaces
Default:	Multicast
Options:	Blocked │ Multicast │ Unicast
Function:	Specifies the way multicasts should be forwarded on this interface: not forwarded, forwarded as data link multicasts, or forwarded as data link unicasts. Data link multicasting is not meaningful on point-to-point and NBMA interfaces, and setting ospfMulticastForwarding to 0 effectively disables all multicast forwarding.
Instructions:	If you configured MOSPF globally, specify the way you want IP to forward multicast packets on this interface.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.2.3.5.1.30

Parameter: **Opaque On**
Path: Configuration Manager > Protocols > IP > OSPF > Interfaces
Default: On
Options: On | Off
Function: Controls whether or not opaque LSAs are to be flooded out this interface.
Instructions: If you have enabled the MOSPF opaque capability globally, you can turn it on and off on this interface as required.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.3.5.1.31

RSVP Parameters

RSVP Global Parameters

Parameter: **Enable**
Path: Configuration Manager > Protocols > IP > RSVP > Global
Default: Enable
Options: Enable | Disable
Function: Specifies the state of global RSVP.
Instructions: Disable and reenable global RSVP as required.
MIB Object ID: 1.3.6.1.4.1.18.3.5.16.1.1.1.2

Parameter: **Soloist Slots**
Path: Configuration Manager > Protocols > IP > RSVP > Global
Default: All slots
Options: Slots 1 to 14
Function: Specifies the slot or slots on which RSVP is eligible to run
Instructions: Select a slot or slots for global RSVP.
MIB Object ID: 1.3.6.1.4.1.18.3.5.16.1.1.1.4

Parameter:	**Log Filter**
Path:	Configuration Manager > Protocols > IP > RSVP > Global
Default:	Info Log Filter
Options:	Info Log Filter | Trace Log Filter | Debug Log Filter
Function:	Turns the RSVP log on and off for different levels of RSVP messages.
Instructions:	Select the levels for the RSVP messages you want to log.
MIB Object ID:	1.3.6.1.4.1.18.3.5.16.1.1.1.5

RSVP Interface Parameters

Parameter: Enable

Path: Configuration Manager > Protocols > IP > RSVP > Interfaces
Default: Enable
Options: Enable │ Disable
Function: Sets the state of RSVP on this interface.
Instructions: Disable and reenable RSVP on the interface as required.
MIB Object ID: 1.3.6.1.4.1.18.3.5.16.1.1.6.1.2

Parameter: Refresh Blockade Multiple

Path: Configuration Manager > Protocols > IP > RSVP > Interfaces
Default: 4 intervals
Options: 1 to 65536 intervals
Function: Specifies the number of refresh intervals that RSVP will stay alive in the blockade state.
Instructions: Specify the number of refresh intervals for the blockade state.
MIB Object ID: 1.3.6.1.4.1.18.3.5.16.1.1.6.1.8

Parameter: Refresh Multiple

Path: Configuration Manager > Protocols > IP > RSVP > Interfaces
Default: 3 intervals
Options: 1 to 65536 intervals
Function: Specifies the number of refresh intervals which must elapse before a PATH or RESV message that is not being refreshed will be timed out.
Instructions: Specify the number of refresh intervals for a PATH or RESV message.
MIB Object ID: 1.3.6.1.4.1.18.3.5.16.1.1.6.1.9

Parameter: TTL

Path:	Configuration Manager > Protocols > IP > RSVP > Interfaces
Default:	0 (no TTL override)
Options:	0 to 255
Function:	Specifies a TTL value used on this interface for messages this node originates. If set to 0, the node determines the TTL via other means. This overrides the IP TTL value.
Instructions:	Set the TTL to 0 if you want the node to use the IP TTL value.
MIB Object ID:	1.3.6.1.4.1.18.3.5.16.1.1.6.1.10

Parameter: Refresh Interval

Path:	Configuration Manager > Protocols > IP > RSVP > Interfaces
Default:	3000 hundredths of a seconds (30 seconds)
Options:	An integer indicating the refresh interval in hundredths of a second
Function:	Specifies the minimum period between refresh transmissions of a given PATH or RESV message on an interface.
Instructions:	Specify the interval in hundredths of a second.
MIB Object ID:	1.3.6.1.4.1.18.3.5.16.1.1.6.1.11

Parameter: Route Delay

Path:	Configuration Manager > Protocols > IP > RSVP > Interfaces
Default:	200 hundredths of a second (2 seconds)
Options:	An integer indicating the route delay in hundredths of a second
Function:	Specifies the approximate period from the time a route is changed to the time a resulting message appears on the interface.
Instructions:	Specify the delay period in hundredths of a second.
MIB Object ID:	1.3.6.1.4.1.18.3.5.16.1.1.6.1.12

Parameter: Udp Required

Path: Configuration Manager > Protocols > IP > RSVP > Interfaces

Default: False

Options: True │ False

Function: Specifies whether or not UDP encapsulation is used on this interface.

Instructions: Select True if manual configuration forces RSVP to use UDP encapsulation on the interface.

Select False to disable UDP encapsulation. If you select False, RSVP uses UDP encapsulation only if it determines that a neighbor on this interface also uses UDP encapsulation.

MIB Object ID: 1.3.6.1.4.1.18.3.5.16.1.1.6.1.13

Announce Policy Parameters for Both DVMRP and MOSPF

Use the following descriptions to set DVMRP and MOSPF announce policies.

Parameter: Enable

Path: Configuration Manager > Protocols > IP > Policy Filters > DVMRP > Announce Policies

Path: Configuration Manager > Protocols > IP > Policy Filters > MOSPF > Announce Policies

Default: Enable

Options: Enable │ Disable

Function: Enables or disables this policy.

Instructions: Set to Disable to disable the policy.

MIB Object ID: DVMRP: 1.3.6.1.4.1.18.3.5.3.2.6.16.1.2

MIB Object ID: MOSPF: 1.3.6.1.4.1.18.3.5.3.2.6.14.1.2

Parameter: Name

Path:	Configuration Manager > Protocols > IP > Policy Filters > DVMRP > Announce Policies
Path:	Configuration Manager > Protocols > IP > Policy Filters > MOSPF > Announce Policies
Default:	None
Options:	Any alphanumeric character string
Function:	Identifies this policy.
Instructions:	Enter a unique name for the policy.
MIB Object ID:	DVMRP: 1.3.6.1.4.1.18.3.5.3.2.6.16.1.4
MIB Object ID:	MOSPF: 1.3.6.1.4.1.18.3.5.3.2.6.14.1.4

Parameter: Networks

Path:	Configuration Manager > Protocols > IP > Policy Filters > DVMRP > Announce Policies
Path:	Configuration Manager > Protocols > IP > Policy Filters > MOSPF > Announce Policies
Default:	An empty list
Options:	A list of network identifiers. Each identifier consists of a network number, a mask, and a flag to indicate whether the ID refers to a specific network or a range of networks.
Function:	Specifies which networks will match this policy.
Instructions:	Enter a specific encoding of 0.0.0.0/0.0.0.0 to match the default route. Enter a range encoding of 0.0.0.0/0.0.0.0 to match any route. Enter an empty list to match any route.
MIB Object ID:	DVMRP: 1.3.6.1.4.1.18.3.5.3.2.6.16.1.5
MIB Object ID:	MOSPF: 1.3.6.1.4.1.18.3.5.3.2.6.14.1.5

Parameter: **Action**

Path: Configuration Manager > Protocols > IP > Policy Filters > DVMRP > Announce Policies

Path: Configuration Manager > Protocols > IP > Policy Filters > MOSPF > Announce Policies

Default: DVMRP: Ignore

MOSPF: Announce

Options: DVMRP: Ignore

MOSPF: Announce | Ignore

Function: Specifies whether to advertise a route that matches this policy.

Instructions: DVMRP: Ignore is the only option available. The router drops the route.

MOSPF: To advertise the route, specify Announce. To drop the route, specify Ignore.

MIB Object ID: DVMRP: 1.3.6.1.4.1.18.3.5.3.2.6.16.1.6

MIB Object ID: MOSPF: 1.3.6.1.4.1.18.3.5.3.2.6.14.1.6

Parameter: **Rule Precedence** or **Precedence**

Path: Configuration Manager > Protocols > IP > Policy Filters > DVMRP > Announce Policies

Path: Configuration Manager > Protocols > IP > Policy Filters > MOSPF > Announce Policies

Default: 0

Options: A metric value

Function: Specifies a metric value to be used to compare this policy with other policies that a route may match. A policy with a higher metric takes precedence over a policy with a lower metric. In case of a tie, the protocol uses an internal index value assigned to the policy by IP software. The position of the policy in the list indicates the index value from lowest to highest.

Instructions: Use this parameter to assign precedence to policies that match the same route.

MIB Object ID: DVMRP: 1.3.6.1.4.1.18.3.5.3.2.6.16.1.7

MIB Object ID: MOSPF: 1.3.6.1.4.1.18.3.5.3.2.6.14.1.7

Parameter:	**Advertise**
Path:	Configuration Manager > Protocols > IP > Policy Filters > DVMRP > Announce Policies
Path:	Configuration Manager > Protocols > IP > Policy Filters > MOSPF > Announce Policies
Default:	An empty list
Options:	A list of network identifiers
Function:	Specifies network IDs to include in place of the network IDs listed in the route to be advertised.
Instructions:	Specify a non-null value only if the announce Action parameter is Propagate. The values you enter in the advertise list determine the action taken. If you supply a list of network IDs, these IDs are advertised instead of the actual IDs in the route. If you use the default (an empty list), the actual IDs are advertised. Note that by default, BGP-4 aggregates subnets into their natural network IDs. If you supply a list that includes the encoding 255.255.255.255/ 255.255.255.255, the actual network IDs are advertised along with the other IDs in the advertise list. This allows advertisement of an aggregate or default along with the actual network. If the actual network is a subnet (and the advertising protocol supports subnet advertisements), the subnet is advertised.
MIB Object ID:	DVMRP: 1.3.6.1.4.1.18.3.5.3.2.6.16.1.10
MIB Object ID:	MOSPF: 1.3.6.1.4.1.18.3.5.3.2.6.14.1.10

DVMRP-Specific Announce Policy Parameters

Use the following descriptions to set DVMRP-specific announce policies.

Parameter: Filtered Circuits

Path: Configuration Manager > Protocols > IP > Policy Filters > DVMRP > Announce Policies

Default: An empty list

Options: Leave empty or specify one or more 2-octet circuit numbers.

Function: This is a list of DVMRP circuits. By specifying a circuit in this list, the filter applies to DVMRP advertisements sent using that circuit.

Instructions: If you want this filter to apply to any outbound DVMRP circuit, do not specify any value for this parameter.

If you want this filter to apply to specific outbound DVMRP circuits, specify the circuit numbers in 2-octet strings.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.16.1.22

Parameter: Filtered Tunnels

Path: Configuration Manager > Protocols > IP > Policy Filters > DVMRP > Announce Policies

Default: An empty list

Options: Leave empty or specify one or more 8-octet IP addresses.

Function: This is a list of DVMRP tunnels. If a tunnel interface appears in this list the filter applies to DVMRP advertisements sent via that tunnel. Each tunnel takes 8 octets, the first 4 of which are for the local IP address and the last 4 are for the remote IP address.

Instructions: If you want this filter to apply to any DVMRP tunnel, do not specify any value for this parameter.

If you want this filter to apply to specific DVMRP tunnels, specify the IP addresses in 8-octet strings. Entering all Fs for the first IP address turns off this filter.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.16.1.23

IGMP Group Policy Parameters

Use the following descriptions to set IGMP group policies.

Parameter: Enable

Path: Configuration Manager > Protocols > IP > Policy Filters > IGMP
Default: Enable
Options: Enable | Disable
Function: Enables or disables this policy.
Instructions: Set this parameter as required.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.11.1.2

Parameter: Name

Path: Configuration Manager > Protocols > IP > Policy Filters > IGMP
Default: None
Options: Any alphanumeric character string
Function: Specifies a user name for this policy.
Instructions: Enter a unique name for this policy.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.11.1.4

Parameter: **Sources**

Path: Configuration Manager > Protocols > IP > Policy Filters > IGMP

Default: An empty list

Options: Leave empty or specify one or more sources.

Function: Identifies which sources will match this rule.

Instructions: If you want this filter to match any source, do not specify any value for this parameter.

To specify an exact source address or range of source addresses, enter one or more octet groupings in the following form:

First octet: exact (1) or range (2)

Next 4 octets: source address

Next 4 octets: source mask

An entry with an exact tag matches only the specific source (number and mask). An entry with a range tag matches any prefix that falls in the range indicated by the source and mask.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.11.1.5

Parameter: **Action**

Path: Configuration Manager > Protocols > IP > Policy Filters > IGMP

Default: Ignore

Options: Accept │ Ignore

Function: Specifies whether to accept or ignore the group join.

Instructions: Specify Accept to accept the group join, or Ignore to ignore the group join.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.11.1.6

Parameter: Precedence

Path: Configuration Manager > Protocols > IP > Policy Filters > IGMP

Default: 0

Options: A metric value

Function: Specifies a metric value to be used to compare this policy with other policies that a route may match. A policy with a higher metric takes precedence over a policy with a lower metric. In case of a tie, the protocol uses an internal index value assigned to the policy by IP software. The position of the policy in the list indicates the index value from lowest to highest.

Instructions: Use this parameter to assign precedence to policies that match the same route.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.11.1.8

Parameter: Groups

Path: Configuration Manager > Protocols > IP > Policy Filters > IGMP

Default: An empty list

Options: Leave empty or specify one or more groups.

Function: Identifies which groups match this rule.

Instructions: If you want this filter to match any group, do not specify any value for this parameter.

To match specific groups, enter group number and group mask combinations as follows:

First 4 octets: group number

Next 4 octets: group mask

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.11.1.10

Parameter:	**Circuits**
Path:	Configuration Manager > Protocols > IP > Policy Filters > IGMP
Default:	An empty list
Options:	Leave empty or specify one or more 2-octet circuit numbers.
Function:	Identifies which circuits match this rule.
Instructions:	If you want this filter to match any circuit, do not specify any value for this parameter. If you want this filter to apply to specific circuits, enter the circuit numbers in 2-octet strings.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.2.6.11.1.11

Parameter:	**Senders**
Path:	Configuration Manager > Protocols > IP > Policy Filters > IGMP
Default:	An empty list
Options:	Leave empty or specify one or more sender address and sender mask octet combinations.
Function:	Identifies which senders match this rule.
Instructions:	If you want this filter to match any sender, do not specify any value for this parameter. To match specific senders, enter sender address and sender mask combinations as follows: First 4 octets: sender address Next 4 octets: sender mask
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.2.6.11.1.12

MTM Static Forwarding Policy Parameters

Use the following descriptions to set MTM static forwarding policies.

Parameter: Enable

Path: Configuration Manager > Protocols > IP > Policy Filters > MTM
Default: Enable
Options: Enable | Disable
Function: Enables or disables this policy.
Instructions: Set to Disable to disable the policy.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.12.1.2

Parameter: Name

Path: Configuration Manager > Protocols > IP > Policy Filters > MTM
Default: None
Options: Any alphanumeric character string
Function: Identifies this policy.
Instructions: Enter a unique name for the policy.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.12.1.4

Parameter: Groups

Path: Configuration Manager > Protocols > IP > Policy Filters > MTM
Default: An empty list
Options: Leave empty or specify one or more groups.
Function: Identifies which groups match this rule.
Instructions: If you want this filter to match any group, do not specify any value for this parameter.

To match specific groups, enter group number and group mask combinations as follows:

First 4 octets: group number

Next 4 octets: group mask

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.12.1.5

Parameter: Preference

Path: Configuration Manager > Protocols > IP > Policy Filters > MTM

Default: 1

Options: 0 | any integer from 1 to 16

Function: Accept the default (1) setting or assign a nonzero value (from 1 to 16) if you want the policy to overwrite multicast protocols. Specify 0 if you want multicast protocols to overwrite the policy.

If the policy can overwrite protocols, it makes the forwarding decisions. If protocols can overwrite the policy, the protocols make the forwarding decisions.

Instructions: Accept the default to allow the policy to overwrite the multicast protocols. Specify 1 to allow the protocols to overwrite the policy filter.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.12.1.7

Parameter: Precedence

Path: Configuration Manager > Protocols > IP > Policy Filters > MTM

Default: 0

Options: A metric value

Function: Specifies a metric value to compare this policy with other policies that a route may match. A policy with a higher metric takes precedence over a policy with a lower metric. In case of a tie, the protocol uses an internal index value assigned to the policy by IP software. The position of the policy in the list indicates the index value from lowest to highest.

Instructions: Use this parameter to assign precedence to policies that match the same route.

MIB Object ID: MOSPF: 1.3.6.1.4.1.18.3.5.3.2.6.12.1.8

Parameter: **Sources**

Path: Configuration Manager > Protocols > IP > Policy Filters > MTM

Default: An empty list

Options: Leave empty or specify one or more sources.

Function: Identifies which sources will match this rule.

Instructions: If you want this filter to match any source, do not specify any value for this parameter.

To specify an exact source address or range of source addresses, enter one or more octet groupings in the following form:

First octet: exact (1) or range (2)

Next 4 octets: source address

Next 4 octets: source mask

An entry with an exact tag matches only the specific source (number and mask). An entry with a range tag matches any prefix that falls in the range indicated by the source and mask.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.12.1.10

Parameter: **In Circuits**

Path: Configuration Manager > Protocols > IP > Policy Filters > MTM

Default: An empty list

Options: Leave empty or specify one or more 2-octet circuit numbers.

Function: Lists inbound circuits.

Instructions: If you do not want this circuit to accept any inbound packets, leave the value for this parameter empty.

If you want this circuit to accept inbound packets, enter the circuit number or numbers, in 2-octet strings.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.2.6.12.1.11

Parameter: Out Circuits

Path:	Configuration Manager > Protocols > IP > Policy Filters > MTM
Default:	An empty list
Options:	Leave empty or specify one or more outbound circuit number and time-to-live (TTL) threshold octet combinations.
Function:	Lists outbound circuits.
Instructions:	If you do not want this circuit to forward any packets affected by this filter, leave the value for this parameter empty. To define a circuit number and TTL threshold from which you want to forward packets, enter the octets as follows: First 2 octets: circuit number Next 2 octets: TTL threshold
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.2.6.12.1.12

IGMP Boundary Group Parameters

Use the following descriptions to set IGMP boundary group parameters.

Parameter: Enable

Path:	Configuration Manager > Protocols > IP > Multicast > IGMP > Boundaries
Default:	Enabled
Options:	Enabled | Disabled
Function:	Specifies whether this record is enabled or disabled.
Instructions:	To disable the boundary group record, enter Disabled.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.13.5.1.2

Parameter: Group Address

Path:	Configuration Manager > Protocols > IP > Multicast > IGMP > Boundaries
Default:	None
Options:	A valid group address.
Function:	Specifies the address of a multicast host group.
Instructions:	Enter a group address to define this IGMP boundary record.
MIB Object ID:	1.3.6.1.4.1.18.3.5.3.13.5.1.3

Parameter: Prefix Length

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Boundaries
Default: None
Options: A valid prefix for the group address.
Function: Specifies a prefix for the multicast host group address.
Instructions: Enter an address prefix to define this IGMP boundary record.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.5.1.

Parameter: Circuit List

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Boundaries
Default: None
Options: A list of one or more circuit addresses.
Function: Specifies a list of circuit addresses for this boundary definition.
Instructions: Specify each circuit with a 2-octet address.
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.5.1.

Parameter: Tunnel List

Path: Configuration Manager > Protocols > IP > Multicast > IGMP > Boundaries
Default: None
Options: A list of one or more multicast tunnels
Function: Specifies a list of tunnels for this boundary address.
Instructions: Specify each tunnel with an eight-octet address, four octets for the local IP address (the local end of the tunnel) and four octets for the remote IP address (the remote end of the tunnel).
MIB Object ID: 1.3.6.1.4.1.18.3.5.3.13.5.1.

Appendix B
Multicasting Tools

This appendix describes Bay Networks Technician Interface tools that allow you to troubleshoot a multicast network. To use the tools, issue the following Technician Interface commands:

Multicast Commands	Page
mtrace	B-2
mrinfo	B-4
rsvp	B-5

mtrace

The **mtrace** command allows you trace the branch of a multicast tree from a source to a receiver for a particular multicast group. Each branch of the tree is a data path consisting of multiple hops. Mtrace displays statistics about packet rates and losses for each hop along the path.

To display Mtrace information, enter the **mtrace** command at the Technician Interface as follows:

mtrace [<*options*>] <*source*> <*receiver*> [<*group*>]

<*options*> = [**-e** <*extra_hops*>**>** | **-g** <*gateway*>**>** | **-i** <*if_addr*>**>** | **-M** | **-m** <*max_hops*>**>** | **-q** <*nqueries*>**>** | **-r** <*resp_dest*>**>** | **-s** | **-S** <*statint*>**>** | **-t** <*ttl*>**>** | **-U** | **-v** | **-w** <*wait*>**>**]

Table B-1 explains the meanings of each **mtrace** option in more detail.

Table B-1. Mtrace Options

Option	Meaning
-e <*extra_hops*>	Mtrace tries to trace extra hops past a nonresponding router. The <*extrahops*> value is an integer.
-g <*gateway*>	Mtrace sends the trace query via a unicast packet directly to the multicast router <*gateway*> you specify.
-i <*if_addr*>	Mtrace uses <*if_address*> as the local interface address for sending the trace query and as the default address for the receiver and the response destination. The <*if_address*> is an IP address in dotted-decimal notation.
-M	Mtrace requests the response using a multicast address.
-m <*max_hops*>	Mtrace sets to integer the maximum number of hops that are traced from the receiver back to the source. The default <*max_hops*> value is 32.
-q <*nqueries*>	Mtrace sets the maximum number of query attempts to integer. The default for <*nqueries*> value is 3.
-r <*resp_dest*>	Mtrace sends the trace response to host (that is, the response destination) rather than to the host on which Mtrace is running, or to a multicast address other than the one regisitered for this purpose (224.0.1.32).
-s	Mtrace prints a short form output including only the multicast path and not the packet rate and loss statistics.

(continued)

Table B-1. Mtrace Options *(continued)*

Option	Meaning
-S *<statint>*	Change the interval between statistics gathering traces to interval seconds. The default *<statint>* value is 10 seconds.
-t *<ttl>*	Mtrace sets the time-to-live (TTL) for multicast trace queries and responses to the value you specify. TTL equals the number of hops. The default *<ttl>* value is 127 hops. For local queries to the "all queries" multicast gtroup, the default is 1 hop.
-U	Mtrace always requests the response using unicast rather than attempting multicast first.
-v	Mtrace uses verbose mode. In verbose mode, Mtrace shows hop times on the initial trace and statistics display. Mtrace also shows the route that was used to forward the initial trace.
-w *<wait>*	Mtrace sets the time to wait for a trace response to seconds. The default *<wait>* value is 3 seconds.

<source> is the source of the multicast tree.

<destination> is the receiver for a particular multicast group.

[*<group>*] is a multicast group. The default group is 224.2.0.1. If you do not specify a group, Mtrace does not display statistics.

For example, the following **mtrace** command specifies source 192.32.27.193, destination 192.32.199.162, and group 224.2.0.1.

```
$ mtrace 192.32.27.193 192.32.199.162 224.2.0.1
Mtrace from 192.32.27.193 to 192.32.199.162 via group 224.2.0.1
Querying full reverse path...
  0  192.32.199.162
 -1  192.32.199.162  DVMRP  thresh^ 1
 -2  192.32.27.193
Round trip time 1039 ms; total ttl of 2 required.
Waiting to accumulate statistics...
  Source        Response Dest    Overall     Packet Statistics For
Traffic From
192.32.27.193   192.32.199.161   Packet      192.32.27.193 To
224.2.0.1
     v       __/  rtt    3ms     Rate        Lost/Sent = Pct  Rate
192.32.27.193
192.32.199.162
     v      \__   ttl    2         0 pps
192.32.199.162     * * *
  Receiver      Query Source
```

mrinfo

The **mrinfo** command displays the capabilities of a DVMRP multicast router. It shows whether the router supports mtrace and pruning, provides revision information, and provides the link characteristics for every link on the router.

To display Mrinfo information, enter the **mrinfo** command at the Technician Interface as follows:

mrinfo [<*options*>] <*router_address*>

<*options*> = [< **-r** <*retry_count*>**>** | **-t** <*timeout_count*>]

Table B-2 explains the meanings of each **mrinfo** option in more detail.

Table B-2. Mrinfo Options

Option	Meaning
-r <*retry_count*>	Mrinfo sets the neighbor query retry limit to <*retry_count*>. The default is 3 retries.
-t <*timeout_count*>	Mrinfo sets the number of seconds to wait for neighbor query reply to <*timeout_count*>. The default timeout is 3 seconds.

<*router_address*> is the address of the DVMRP router whose capabilities you want to display.

For example, the following **mrinfo** command displays the capabilities of DVMRP router 192.32.27.46. The DVMRP router is running version 3.255 and supports pruning and Mtrace.

```
$ mrinfo 192.32.27.46
192.32.27.46 [version 3.255,prune,genid,mtrace]:
  192.32.27.46 -> 192.32.27.39 [1/1]
  192.32.27.46 -> 192.32.27.47 [1/1]
  192.32.27.46 -> 192.32.191.2 [1/1/tunnel]
  192.32.27.161 -> 192.32.27.162 [1/1]
```

rsvp

The **rsvp** command allows you to view information about RSVP and set global configuration parameters.

Enter the **rsvp** command at the Technician Interface as follows:

rsvp *<subcommand>* [*<options>*]

<subcommand> = <**session** | **phop** | **oi** | **path** | **resv**>

Table B-3 explains the meanings of each **rsvp** subcommand in more detail.

Table B-3. IP Subcommands

Subcommand	System Displays
session	Known RSVP sessions
phop	Known RSVP previous hops
oi	Known RSVP outgoing interfaces
path	The RSVP path state
resv	The RSVP RESV state
blockade	The RSVP blockade state

<options> = [**-d** *<destination IP>* [*<protocol ID>*|*<destination port>*] | **-p** *<previous hop>* | **-f** *<source IP>* [*<source port>*] | **-n** *<next hop>*]

The *<options>* apply to subcommands, as described in Table B-4.

Table B-4. Options for rsvp Subcommands

Option	Effect	Applicable Subcommands
-d *<destination IP>* [*<protocol ID>* | *<destination port>*]	Retrieves RSVP data for the session you specify	session | phop | oi | path | resv
-p *<previous hop>*	Retrieves only sessions with a previous hop of *<previous hop>*	phop | path | resv
-f *<source IP>* [*<source port>*]	Retrieves only oi, path, or resv information for sessions with a source address of *<source IP>* and, optionally, a source port of *<source port>*	oi | path | resv
-n *<next hop>*	Retrieves only reservation request information with a next hop of *<next hop>*	resv

For example, the following **rsvp** command specifies the RSVP previous hops:

```
$ rsvp phop

RSVP Previous Hops:

      Session
IP dest/protocol/dest port   Previous Hop
--------------------------   ---------------
225.1.1.1 17 5000            199.1.4.5
225.1.1.1 17 5000            200.1.1.212
225.1.1.1 17 5000            201.1.1.212

   3 previous hops matched
```

Index

A

acronyms, xvii
addresses
  multicast, 1-3
  supplying for tunnel, 4-34
Advertise Self parameter, 4-29, A-9

B

Bandwidth, A-27
Bandwidth Interval (Secs) parameter, 8-8, A-27
border router (BR) in multicasting, 5-2
boundary router (ASBR) in multicasting, 5-2

C

Circuit Name parameter, 3-21, A-19
Control, A-13
Control Message Mode parameter, 4-43, A-13
conventions, text, xvi

D

Debug Level parameter, 4-19, A-5
debug messages, logging, 4-19
Debug parameter, 3-9
default route, DVMRP circuit, listening for, 4-31
Delay, A-38
Designated Router Timeout parameter, 3-18, A-21
Deterministic Mcast Hold Down parameter, 6-3, A-32
deterministic mode for MOSPF, 5-6
disabling
  advertisement of local networks, 4-29
  deterministic MOSPF, 5-6
  DVMRP circuit, 4-22
  DVMRP global, 4-9
  IGMP global, 3-5
  IGMP interface, 3-14
  MOSPF, 5-4
  multicast support on unicast tunnel, 4-23
  RSVP on an interface, 7-7
  tunnels, 4-35
  UDP encapsulation, 7-13
DVMRP
  accepting report from nonstandard neighbor, 3-23, 3-24, 4-44, 4-45, 5-12
  calculating route metric, 4-24
  choosing a route, 4-5
  comparing route costs, 4-24
  cost of a tunnel, 4-37
  enabling and disabling, 4-9
    advertisement of local networks, 4-29
    circuit, 4-22
  encapsulation mode for multicast datagrams, 4-36
  estimating number of routes for, 4-18
  forwarding table size, 4-27
  listening for default route, 4-31
  logging debug messages, 4-19
  number of routes, 4-20
  probe interval, 4-16
  route switch interval, 4-17
  threshold value of tunnel, 4-38
  tree pruning, 4-11
DVMRP (Distance Vector Multicast Routing Protocol)
  starting, 2-3
Dynamic TTL parameter, 5-9, A-33

E

educational services, xix

Enable parameter
- DVMRP
  - circuit, 4-22, A-7
  - global, 4-9, A-2
  - tunnel, 4-35, A-11
- IGMP
  - global, 3-5, A-15
  - interface, 3-14, A-20
- RSVP, 7-7

enabling
- advertisement of local networks, 4-29
- deterministic MOSPF, 5-6
- DVMRP circuit, 4-22
- DVMRP global, 4-9
- IGMP global, 3-5
- IGMP interface, 3-14
- MOSPF, 5-4
- MOSPF on an OSPF interface, 5-10
- multicast support on unicast tunnel, 4-23
- RSVP on an interface, 7-7
- tunnels, 4-35
- UDP encapsulation, 7-13

Encapsulation Mode parameter, 4-36, A-11

Estimated Bandwidth parameter, 2-5, 8-4

Estimated Groups parameter, 3-7, A-16

Estimated Routes parameter, 4-18, A-4

F

First Fit multiline select algorithm, 8-12

Forward Cache Limit parameter, 3-11, A-17

Forward Cache Size parameter, 4-27, 4-39, A-8, A-12

Forward Cache TTL parameter, 4-28, 4-40, A-9, A-12

forwarding table, defined, 4-27

Full Update Interval parameter, 4-10, A-2

G

Garbage Timeout parameter, 4-13, A-4

H

host groups, types of, 1-2

I

IGMP (Internet Group Management Protocol), 1-3
- adding a static host entry, 3-21
- designated router timeout interval, 3-18
- enabling and disabling
  - global, 3-5
  - interface, 3-14
- estimating number of groups, 3-6
- function of, 3-2
- host leave message, 3-3
- host repots, 3-3
- lifetime of a cache entry for Mtrace, 3-20
- logging, 3-9
- maximum host response time, 3-19
- membership timeout interval, 3-17
- queries, 3-2
- query rate, 3-15
- relay, 9-1
- version threshold time, 3-8

Inflate, A-27

Inflate Reservations Percentage parameter, 8-9, A-27

Interface Membership Timeout parameter, 3-17, A-20

Interface Query Rate parameter, 3-16, A-20

internal router (IR) in multicasting, 5-2

Internet Group Management Protocol
- see IGMP (Internet Group Management Protocol), 1-3

IP Address parameter, A-23
- IP Configuration
  - IGMP and DVMRP, 2-3
  - RSVP, 2-5

J

Join Ack Enable parameter, 3-10, A-16

L

Largest Bandwidth parameter, 8-15, A-30

Largest Buffer parameter, 8-16, A-30

Leaf Timeout parameter, 4-15, A-3
leaky bucket policing algorithm, 8-10
Line Resource Manager
  policing algorithm, 8-7, 8-10
Line Resource Manager (LRM)
  bandwidth interval, 8-8
  inflating reservations, 8-9
  latency for reserved flow packet, 8-14
  maximum number of unreserved packets in queue, 8-11
  multiline select algorithms, 8-12
  multiline threshold bandwidth, 8-13
  overview, 8-2
  traffic queuing algorithm, 8-6
Local IP Address parameter, 4-34, A-14
Log, A-36
Log Filter parameter, 7-6, A-36
logging
  IGMP messages, 3-9
  RSVP messages, 7-6
logging, debug messages, 4-19
LSSR option, 4-36

M

Max Host Response Time parameter, 3-19, A-21
Max Queued Multcast Packets parameter, 5-8, A-33
Max Routes parameter, 4-20, 4-21
Metric parameter, 4-24, 4-37, A-8, A-11
MOSPF (Multicasting Extensions to OSPF), 1-4
  deterministic hold-down feature, 6-3
  deterministic mode, 5-6
  enabling and disabling, 5-4
  enabling on an OSPF interface, 5-10
  forwarding timeout value, 5-7
  nondeterministic mode, 5-6
  opaque capability
    enabling on an interface, 6-6
    globally enabling, 6-5
  overview, 5-1
  starting, 2-4
  types of multicasting support, 5-3
Mtrace Entry Lifetime parameter, 3-20, A-21
Mtrace utility, 3-20
Multicast Deterministic parameter, 5-6, A-31
Multicast Extensions parameter, 2-4, 5-4, A-31
Multicast Forwarding parameter, 5-10, A-34
Multicast Route Pinning parameter, 6-4, A-31
multicasting
  addresses for, 1-3
  aging a route, 4-12
  border router (BR), 5-2
  boundary router (ASBR), 5-2
  comparing routes, 4-7
  creating a shortest path tree, 4-7
  IGMP, 1-3
  internal router (IR), 5-2
  leaf network, 4-7
  threshold, 4-25
  tunnel, 4-2
  types supported by MOSPF, 5-3
Multicasting Extensions to OSPF
  see MOSPF, 1-4
Multiline Select Algorithm parameter, 8-12, A-29
Multiline Threshold Bandwidth parameter, 8-13, A-29

N

Neighbor Probe Interval parameter, 4-16, A-5
Neighbor Timeout parameter, 4-14, A-3
neighbors
  nonstandard, 3-23, 3-24, 4-44, 4-45, 5-12
nondeterministic mode for MOSPF, 5-6

O

Opaque Capability parameter, 6-5, A-32
Opaque On parameter, 6-6, A-35

P

permanent host group, 1-2
Policing Algorithm parameter, 8-7, A-26
policy parameters
  Action (announce), A-41, A-45
  Advertise (announce), A-42
  Enable (announce), A-39, A-44, A-48
  Name (announce), A-40, A-44, A-48

policy parameters (continued)
Networks (announce), A-40
Precedence (announce), A-41, A-46, A-49
Prefix Length parameter, 3-21, A-19
priority queuing, 8-11, A-28
product support, xix
Pruning Enable parameter, 4-11, A-6
pruning the shortest-path tree, 4-11
publications, Bay Networks, xix

Q

QOSPF (Quality of Service Path First)
adding extensions to OSPF, 6-2
functions, 6-1
Quality of Service (QoS), 8-2
queue limit policing algorithm, 8-10

R

Refresh, A-38
Refresh Blockade Multiple parameter, 7-10, A-37
Refresh Interval parameter, 7-8, A-38
Refresh Multiple parameter, 7-9, A-37
Remote IP Address parameter, 4-34, A-15
Report Depend Probe parameter, 4-44, A-10
Reservable Bandwidth parameter, 2-5, 8-5
Reservation Latency parameter, 8-14, A-30
Resource Reservation Protocol
see RSVP (Resource ReSerVation Protocol), 1-4
RFC 1075, 4-36
Round Robin multiline select algorithm, 8-12
Route Delay parameter, 7-12, A-38
Route Depend Probe parameter, 4-32, A-14
Route Enable parameter, 4-23, A-7
Route Expiration Timeout parameter, 4-12, A-3
Route Listen parameter, 4-31, 4-42, A-10
Route Supply parameter, 4-30, 4-41, A-9
Route Switch Timeout parameter, 4-17, A-5
RSVP (Resource ReSerVation Protocol)
estimating bandwidth, 8-4
setting reservable bandwidth, 8-5
starting, 2-5
RSVP (Resource Reservation Protocol)
configuring with the Technician Interface, 1-4
enabling and disabling, 7-7
function, 7-1
lifetime multiplier, 7-9
loading on a slot, 7-5
logging messages, 7-6
refresh blockade multiplier, 7-10
refresh timer, 7-8
route delay value, 7-12
TTL override, 7-11
UDP encapsulation, 7-13

S

Soloist Slots parameter, 7-5
source network
defined, 4-4
starting
DVMRP, 2-3
MOSPF, 2-4
RSVP, 2-5
Static Group Address parameter, 3-21, A-19
Subnet Mask parameter, IP Configuration
IGMP and DVMRP, 2-3
RSVP, 2-5
support, Bay Networks, xix

T

technical publications, xix
technical support, xix
text conventions, xvi
Threshold parameter, 4-26, 4-38, A-8, A-12
threshold values, function of, 4-25
Timeout Value parameter, 5-7, A-32

timer
garbage, 4-13
leaf, 4-15
neighbor report, 4-14
route expiration, 4-12
RSVP default refresh, 7-8
traffic filters, affect on multicast data packets, 1-2
Traffic Queuing Algorithm parameter, 8-6, A-26
transient host group, 1-2
Transmit Bcast Addr parameter, IP Configuration
IGMP and DVMRP, 2-3
RSVP, 2-5
tree pruning, 4-11
Triggered Update Interval parameter, 4-10, A-2
triggered updates, specifying the time between, 4-10
TTL parameter, 7-11
tunnels
addresses for, 4-34
connecting neighbors, 4-2
cost, 4-37
enabling and disabling, 4-35
forwarding table for, 4-39
threshold value for, 4-38
unicast, disabling multicast support on, 4-23

U

Udp Required parameter, 7-13
UnNumbered Assoc Address parameter
IP Configuration
RSVP, 2-5
UnNumbered Assoc Address, IP Configuration
IGMP and DVMRP, 2-3
Unreserved Queue Length parameter, 8-11, A-28
UPD encapsulation, 7-13
updates
setting the interval, 4-10
triggered, 4-10

V

Version Threshold Time parameter, 3-8, A-16